




# Xenium S.P. Ice Quick Install Guide for v 1.6



Attach white PCB to black base as shown in Fig 1 and 2



Use large thin alignment washer for 1.6




Rivit install is optional











Insert single gold wire of adaptor  
(Hint: Gently bend the wire down and across)




With all gold wires in place align adaptor pogo  
pins to the LPC bus)





While pressing down on the adaptor gently tighten the screw.



Ensure all gold wires are in the centre of the through holes




**Make sure the Power Supply is safely covered with the HDD housing.** Temporarily power on the box and check to see that all five LED's illuminate.

In case an LED does not illuminate, gently push corresponding tip of problem wire in order to seat it properly in the through hole  
(HINT: If the wire is sitting outside through hole by pushing the tip you should hear a click.)

Repeat power test to ensure all five LED's illuminate

Before proceeding ensure the box is powered down and power cable removed



Plug in the Xenium power up and have fun :-)

Note: When the Xenium is active the LED indicated by the red arrow should be off