

Key	new	CP	Function
1		X	Presentation mode
2		X	Texture mapping mode
3		X	Surface editing mode
4		X	Source assignment mode
i			Show info
t		X	Add triangle surface
q		X	Add quad surface
g		X	Add grid warp surface
d	a		duplicate surface
p		X	toggle perspective warping (quad surfaces only)
]	v		add columns to grid surface (grid warp surfaces only)
[b		remove columns from grid surface (grid warp surfaces only)
}	m		add rows to grid surface (grid warp surfaces only)
{	n		remove rows from grid surface (grid warp surfaces only)
.			select next surface (projection mapping mode only)
,			select previous surface (projection mapping mode only)
>	l		select next vertex
<	k		select previous vertex
f			Toggle fullscreen
s			Save composition
z			Undo
BACKSPACE	d	X	Delete surface
SPACE			Deselect surface (projection mapping mode)
TAB	5		Select next source (no need to use the source selection interface)
Arrow keys			Move selection. If no surface is selected in the projection mapping mode, all surfaces are moved.
up key	8		
down key	9		
left key	7	X	
Right key	0	X	