

Boppin' Beaver Switch Adapted Toy

SUMMARY

Title

Boppin' Beaver Toy Adaptation

Subtitle

A switch adapted toy that sings, teaches ABC, 123s, and plays simple games.

Overview

The switch adapted Boppin' Beaver sings and dances and can be controlled with accessible switches that have a 3.5 mm jack. The beaver is a Fisher Price toy that teaches ABCs, 123, opposites, and simple games.

Usage

You can use the Smooth Moves Sloth by plugging in a switch. Then, press the switches to activate the sloth.

Cost

Build Instructions

SKILLS REQUIRED

- **Mechanics**
- **Soldering**

TIME REQUIRED

< 1hr

TOOLS

- Drill with ¼" drill bit
- Wire Strippers
- Flush Cutters
- Phillips screwdriver
- Soldering Iron
- Solder
- Ruler

Boppin' Beaver Switch Adapted Toy

SUMMARY



COMPONENTS

- Boppin' Beaver Linkimal
- Mono jack
- Wire

Attribution

Documentation created by Neil Squire / Makers Making Change - based on instructional video by "Santa" Jerry Galland.

Instructional Video by "Santa" Jerry Galland.