


Ivy Nunchuck Joystick Adapter

USER GUIDE

Introduction

The Ivy Nunchuck Joystick Adapter enables a Nunchuck controller to be used as a USB HID Mouse or USB HID Gamepad. The Nunchuck Controller has a thumb joystick and two buttons. A light on the enclosure of the Ivy Nunchuck Joystick Adapter indicates which operating mode the device is in.

Features



Setup

1. Plug the **Nunchuck Controller** into the **Ivy Nunchuck Joystick Adapter**.
2. Plug the USB-C end of the USB Cable into the **Ivy Nunchuck Joystick Adapter**.
3. Connected the other end of the USB cable to the Host Device (use a suitable adapter if necessary).

Swapping between Mouse and Gamepad Mode

1. Reset the **Adapter**. Before the red light turns off, press and hold the two buttons on the Nunchuck until the light turns green, then release the two buttons.
2. Press the C button to toggle between modes. The light on the Adapter will indicate the current mode: USB HID Mouse - Yellow, USB HID Gamepad - Blue.
3. Press and release the Z button to set the mode. The light will blink.
4. Cycle the power by pressing the reset button or disconnecting and reconnecting USB cable.

Ivy Nunchuck Joystick Adapter

USER GUIDE

Usage

Mouse Mode (Yellow)

1. Move the joystick to control the cursor.
2. Press the C button to left click.
3. Press the Z button to right click.
4. Hold the Z button for 2 seconds to enter scroll mode. LED will turn purple. Move joystick to scroll. Press Z button again to exit scroll mode.

Gamepad Mode (Blue)

1. Move the joystick to control the joystick.
2. Press the C button to activate Button 1.
3. Press the Z button to activate Button 2.

Mapping

Nunchuck	Mouse	Joystick		
		PC	XAC (Left USB)	XAC (Right USB)
Joystick	Cursor movement (Scroll movement if in scroll mode (purple LED))	Joystick movement	Left Thumbstick	Right Thumbstick
C	Left click	Button 1	X1	View
Z	Right click (Long press -> enter scroll mode)	Button 2	X2	Menu

Host Device Compatibility

- USB HID Mouse: PC, Mac, Android Smartphone, Apple Smartphone (iOS 13+)
- USB HID Gamepad: PC, Xbox Adaptive Controller

Specifications

Nunchuck Joystick Range of Motion	$\pm 30^\circ$
Nunchuck Joystick Range of Motion	± 15 mm
Nunchuck Joystick Activation Force	100 grams
Nunchuck Weight	68 grams
Enclosure Height	25 mm
Enclosure Width	45 mm
Enclosure Length	51 mm
Enclosure Weight	21 grams

Cleaning

The outside of the enclosure can be cleaned with a damp cloth. Do not use hot water. Do not submerge the device.



© 2023 by Neil Squire.

This work is licensed under the CC BY SA 4.0 License: <http://creativecommons.org/licenses/by-sa/4.0>

Files available at <https://github.com/makersmakingchange/Ivy-Nunchuck-Adapter>