

- At last fixture, the DMX cable has to be terminated with a terminator to reduce signal

errors. Solder a 120-ohm 1/4W resistor between pin2(DMX-) and pin 3(DMX+) into.

Channel:

Channel 1= Blue

Channel 2= Green

Channel 3= Red

Channel 4= Auto Color Chase

Channel 5= Strobe

Channel 6= Dimmer

AGENT: