


RN-52

DFU MODE

CMD MODE

MICRO USB

FTDI



Power Supply

fritzing