



FUSELAGE TOP VIEW

FUSELAGE BOTTOM VIEW

FUSELAGE CONSTRUCTION

FIN & RUDDER CONSTRUCTION

TAIL GUNNERS CANOPY DETAIL VIEW

STEERABLE TAIL WHEEL DETAIL VIEW

1. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 2. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 3. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 4. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 5. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 6. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 7. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 8. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 9. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 10. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 11. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 12. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 13. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 14. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 15. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 16. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 17. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 18. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 19. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 20. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 21. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 22. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 23. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 24. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage. 25. Use the 1/8" x 1/8" x 1/8" block to form the base of the fuselage.

CANOPY & TURRET NOTES

1. The canopy and turret are shown in the plan view. 2. The canopy and turret are shown in the plan view. 3. The canopy and turret are shown in the plan view. 4. The canopy and turret are shown in the plan view. 5. The canopy and turret are shown in the plan view. 6. The canopy and turret are shown in the plan view. 7. The canopy and turret are shown in the plan view. 8. The canopy and turret are shown in the plan view. 9. The canopy and turret are shown in the plan view. 10. The canopy and turret are shown in the plan view. 11. The canopy and turret are shown in the plan view. 12. The canopy and turret are shown in the plan view. 13. The canopy and turret are shown in the plan view. 14. The canopy and turret are shown in the plan view. 15. The canopy and turret are shown in the plan view. 16. The canopy and turret are shown in the plan view. 17. The canopy and turret are shown in the plan view. 18. The canopy and turret are shown in the plan view. 19. The canopy and turret are shown in the plan view. 20. The canopy and turret are shown in the plan view. 21. The canopy and turret are shown in the plan view. 22. The canopy and turret are shown in the plan view. 23. The canopy and turret are shown in the plan view. 24. The canopy and turret are shown in the plan view. 25. The canopy and turret are shown in the plan view.

NOTE

For greater clarity and the removal of minor imperfections, the canopy may be sealed with an adhesive. The type of adhesive used is not specified, but should be clear and dry. The adhesive should be applied to the inside of the canopy and the outside of the turret. The adhesive should be allowed to dry for 24 hours before the model is painted.

NOTE TO THE MODELER

All formers and ribs are shown actual size to make "balsa" building easily accomplished from these plans, and to facilitate any repairs that may be necessary.



**B-17F**  
*Flying Fortress*



