




IMPORTANT: This PCB does not have UART Chip.
USB just connects to the IOs specified in C3-mini datasheet
for USB_D- (18) and USB_D+ (19)
TOUCH_INT IO8 needs to be pulled-high during boot to enter
download mode and be able to program the MCU



- H1 MountingHole
- H2 Not included in PCB (no space) MountingHole
- H3 MountingHole
- H4 MountingHole