



Memory Protection

Lecture 9



Memory Protection

- Memory Protection Unit
- Memory Management Unit



Memory Protection

ARM: MPU, RISC-V: PMP



Bibliography

for this section

Joseph Yiu, *The Definitive Guide to ARM® Cortex®-M0 and Cortex-M0+ Processors, 2nd Edition*

- Chapter 12 - *Memory Protection Unit*



Memory Protection

memory access defined region by region

- **restricts** access to **physical memory**
- uses **physical addresses**

The processor works in three modes:

- **machine** mode (*optional*) - used at boot, allows access to everything
- **supervisor** mode - restricts access to some registers and accesses memory through Memory Protection EL2 (*if machine mode exists*)
- **user** mode - allows only ALU and memory access through Memory Protection





MPU for RP2040


Cortex-M0+

The processor works in three modes:

- **handler** mode - *no restrictions* - used while executing ISRs and Exception Handlers
- **thread** mode
 - **privileged** *no restrictions* - usually used for the operating system
 - **unprivileged** mode - *allows only ALU and memory access through Memory Protection* - used for applications

MPU allows 8 regions

- each region has up to 8 subregions
- permissions R W X





Memory Protection Unit

Cortex-M MPU



- allows the definition of *memory regions*
- regions can overlap, *highest region number takes priority*
- regions have access permissions (similar to rwx)

$$region_size = \min(256, 2^{size})$$


$$base_address = region_size \times N$$





Memory Protection Unit

Access Protection



AP Access Protection

XN eXecute Never


- faults if MCU has to read the next instruction from an *XN* region

AP	Privileged Mode	Unprivileged Mode
000	No Access	No Access
001	Read/Write	No Access
010	Read/Write	Read only
011	Read/Write	Read/Write
100	Do not use	Do not use
101	Read only	No Access
110	Read only	Read only
111	Read/Write	Read only



Subregions

- each region is divided in 8 subregion
- each bit in **Subregion Disable** disables a subregion
- a disabled subregion triggers a fault if accessed





Subregions' Usage

improve granularity

$$region_size = \min(256, 2^{size})$$

$$base_address = region_size \times N$$

$$subregion_size = \frac{region_size}{8}$$

- a 5K region is not allowed (5K is not a power of 2)
- use two 4K regions back to back
- disable 6 of the subregions (subregion is 512B)



Memory Layout

protection

Flash

- **Code** - *read and execute*
- **.rodata** - constants - *read only*
- **.data** - *in flash* - initialized global variables
 - is copied to RAM at startup by the `init` function
 - *should not be accessed after startup*

RAM

- **stack** - *read and write*
 - *usually protected by unaccessible memory before and after*
- **.data** - *in RAM* - global variables - *read and write*
- **.bss** - global variables (not initialized or initialized to `0`) - *read and write*



* drawing is not at scale, code and data are significantly greater than the interrupt vector





Memory Management

MMU



Bibliography

for this section

1. **Andrew Tanenbaum**, *Modern Operating Systems (4th edition)*

- Chapter 3 - *Memory Management*
 - Subchapter 3.3 - *Virtual Memory*

2. **Philipp Oppermann**, *Writing an OS in Rust*

- *Introduction to Paging*
- *Paging Implementation*



Memory Management

memory access defined page by page

- uses *logical addresses*
- **translates** to *physical addresses*

The processor works in at least two modes:

- **supervisor mode**
 - restricts access to some registers
 - accesses virtual addresses through Memory Protection (if machine mode exists)
- **user mode**
 - allows only ALU and memory load and store
 - accesses memory access through the Memory Management Unit (MMU)





Paging

the memory *unit* is the page

- Physical Memory (RAM) is divided in **frames**
- Logical Memory is divided in **pages**
- $page = frame = 4 \text{ KB}$ (usually)

logical addresses are translated to *physical addresses* using a **page table**

the **page table** is located in the **physical memory**

- each memory access requires at least memory 2 accesses





Address Translation

page to frame

the logic address is divided in two parts:

- *page index*
- *offset* withing the page

the MMU translates every logic address into a physical address using a *page table*





Translation Lookaside Buffer (TLB)

caching address translation

the **page table** is stored in RAM

each memory access **requires 2 accesses**

1. read the page table entry to translate the address
2. the requested access





Page Directory

caching address translation


$$size_{table} = \frac{size_{ram}}{size_{page}}$$

- each table entry is 4B
- the address space is 4GB
(for 32 bits processors)

$$size_{table_32_bits} = \frac{2^{32}}{4 \times 2^{10}}$$

$$size_{table_32_bits} = 4MB$$

RAM was counted in MB
when paging started being
used



two levels, page directory and table, usually used for 32 bits systems



Page Table Entry

for x86 - 32 bits

this is one entry of the page table

- **P** - is the page's frame present in RAM?
- **R/W** - read only or read write access
- **U/S** - can the page be accessed in user mode?
- **D** and **A** - has this page been written since the OS has reset these bits?
- **AVL** - bits available for the OS to use, ignored by MMU





Page Table Entry

for x86 - 32 bits with PAE

this is one entry of the page table using Physical Address Extension (PAE)

- **XD** - eXecute Disable (aka *DEP*), if set triggers a fault if an instruction is read from the page
- **PK** - Protection Keys, allows user mode to set protection (64 bit only)





Microcontroller (MCU)

Integrated in embedded systems for certain tasks

- low operating frequency (MHz)
- a lot of I/O ports
- controls hardware
- does not require an Operating System
- costs \$0.1 - \$25
- uses **Memory Protection Unit**




Microprocessor (CPU)

General purpose, for PC & workstations

- high operating frequency (GHz)
- limited number of I/O ports
- usually requires an Operating System
- costs \$75 - \$500
- uses **Memory Management Unit**





Conclusion

we discussed about

- Memory Protection Unit
- Memory Management Unit