

# ***GENERAL PURPOSE ENGINE***

**GXV340A2  
GXV340A2  
(PROPANE ENGINE)**

**PARTS CATALOGUE**

**1**

---

FOREWORD INDEX

**1**

---

ENGINE GROUP

**2**

---

PART NUMBER INDEX

**3**

---

PART NAME INDEX

**4**

---



### Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of February 01, 2005.**
- See the parts catalogue news for any revision that is made after February 01, 2005.
- **Always specify the part number when ordering a part.**
  - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
  - Note that the illustrations (part drawings) can differ from the actual parts in shape.  
They are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your Honda distributor.**


Initial version issue date February 01, 2005  
Honda Motor Co., Ltd.

### CONTENTS

	Page	Address No.	
• How to refer to the part information .....	2	B 2	<b>1</b>
• Part catalogue structure .....	3	B 3	
• When the parts were revised .....	4	B 4	
• Abbreviations used in the parts catalogue.....	4	B 4	
• How to check the part block and serial numbers.....	5	B 5	
• Models, parts catalogue codes and applicable serial numbers .....	6	B 6	
• Features of each type .....	7	B 7	
• Fuel hose, general purpose hoses and vinyl hose .....	8	B 8	
• Illustrated index .....	9	B 9	
• ENGINE GROUP .....	12	C 1	<b>2</b>
• PART NO. INDEX.....	39	E 1	<b>3</b>
• PART NAME INDEX.....	41	F 1	<b>4</b>

## How to refer to the part information

## A Reference with "Illustrated index"



## B Reference with "Part number index"

PART NO. INDEX					
Part Number	Address	Page	Ref.	Part Number	Address Page
06000				15212-ZW9-000	1-C14 3C
06316-ZW9-000	1-G9	88	1	15220-ZW9-003	1-C14 3C
11000				15332-ZW9-000	1-E8 55
11300-ZW9-405	1-C11	27	1	15332-ZW9-A30	1-E11 58
11300-ZW9-406	1-C11	27	1	15400-PFB-004	1-C11 27
11340-ZW9-000	1-C11	27	2	15422-ZW9-000	1-C14 3C
11342-ZW9-000	1-C11	27	3	15473-881-000	1-C14 3C
11381-ZW9-003	1-C12	28	1	15474-ZW9-000	1-C14 3C
				15611-921-000	1-C10 26
				15655-ZW9-000	1-C11 27
12000				16000	
12000-ZW9-405ZA	1-C11	27	4	16010-ZV4-005	1-D4 36
12155-ZV4-A00	1-C13	29	1	16011-ZV4-005	1-D4 36
12166-ZW9-000	1-C10	26	1	16013-ZW9-003	1-D4 36
12209-GB4-681	1-C16	32	1	16016-ZW9-003	1-D4 36
12210-ZW9-405ZA	1-C10	26	2	16016-ZW9-721	1-D4 36
12216-ZE2-300	1-E8	55	1	16023-ZW9-003	1-D4 36
	1-E11	58	1	16024-ZV4-650	1-D4 36
				16028-ZV4-650	1-D4 36

## C Reference with "Part name index"

PART NAME INDEX					
Part name	Address	Page	Ref.		
[ A ]					
ABSORBER, FUEL	1-E15	62	5	BOLT,	
ARMATURE COMP.	1-D11	43	7	BOLT,	
ARM COMP., LINK JOINT	1-G6	85	18	BOLT,	
ARM COMP., SHIFT LINK	1-G6	85	14	BOLT,	
ARM COMP., TILT	1-F15	79	20		
ARM, FUEL PUMP ROCKER	1-C16	32	4		
ARM, REVERSE LOCK	1-F15	79	18		
ARM, SHIFT LINK	1-F11	74	7		
ARM, STOPPER	1-D1	33	12	BOLT,	
ARM, THROTTLE REMOTE	1-F11	74	6		
ARM, VALVE ROCKER	1-C16	32	3		
[ B ]					
BAG, TOOL, 160MM	1-G5	84	10		
BAND	1-G6	86	37		
BAND B1, WIRE	1-F6	69	1		
BAND, CORD	1-F3	67	18	BOLT,	
BAND, TUBE CLIP, 11MM	1-E15	63	20		
BAND, TUBE CLIP, 12.5MM	1-E15	63	19	BOLT,	

Address No. 1-C10

E-2 CYLINDER HEAD

Block No.

Ref No.

FR


ZW83-B0200

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			BF 9901 BFP 9901 BF 1001 BFP 1001 BF 1081 BFP 1081		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2 2 2 2 2 2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1 1 1 1 1 1		
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1 1 1 1 1 1		
4	12310-ZW9-000	COVER COMP., HEAD	1 1 1 1 1 1		
5	12312-ZW9-000	PACKING, HEAD COVER	1 1 1 1 1 1		
6	15611-921-000	CAP, OIL	1 1 1 1 1 1		
7	16617-ZW9-000	HOLDER, CABLE	1 1 1 1 1 1		
	16617-ZW9-010		1 1 1 1 1 1	1001800	SC,SG LHC,LHD
8	35673-ZW5-003	SENSOR ASSY., WATER	1 1 1 1 1 1		
9	90003-ZW9-000	BOLT, FLANGE, 6X22	4 4 4 4 4 4		
10	90007-ZW9-003	BOLT, FLANGE, 8X83	6 6 6 6 6 6		
11	90011-ZW9-000	BOLT, FLANGE, 6X14(CT200)	1 1 1 1 1 1		
12	90020-ZW9-000	BOLT, FLANGE, 8X40	2 2 2 2 2 2		
13	91025-KJ9-003	OIL SEAL, 20X32X6	1 1 1 1 1 1		
14	91301-805-000	O-RING, 26X2.7	1 1 1 1 1 1		
15	91307-PK2-005	O-RING, 9.5X1.5(HONDA KIKAKI)	1 1 1 1 1 1		
16	98059-55916	PLUG, SPARK (CR5EH-9)	2 2 2 2 2 2		
	98059-55926	PLUG, SPARK (U16FER9)	2 2 2 2 2 2		


Page No.

2000.09.20 E

## Part catalogue structure



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.	Parts catalogue code
			BF	BFP	BF	BFP	BF	BFP		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1	1	1	1	1	1		
		*NHS*								
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1		
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1		
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1		
6	15611-921-000	CAP, OIL	1	1	1	1	1	1		
		(NO GAUGE)								
7	16617-ZW9-000	HOLDER, CABLE	1	1	1	1	1	1		
	16617-ZW9-010		1	1	1	1	1	1		
									SC,S6	
									1001800 LHC,LHD	



## ① Address number

- Address No. is provided (in place of the page No.) to help you refer to the part with the part No. or part name.

## ② Block title ③ Block number

## ④ Service item/Flat rate time

## ⑤ Reference number

- Title number marked with the parenthesis or parentheses indicates that it continues from the previous page.

## ⑥ Part number ⑦ Honda color code

## ⑧ Description

## ⑨ Assemblies

- Sections framed with broken lines in the exploded view drawings are available as complete assemblies. (Their individual parts can also be obtained.)

## ⑩ Color description

## ⑪ Note

- Notes are shown with the parentheses in the part name column.

## ⑫ Required quantity

- Required QTY shown in the parenthesis or parentheses indicates the optional part.
- Required QTY marked with "N" Indicates the optional part that should be selected as needed.
- Required QTY indicates the number of the part used in the block.

## ⑬ Serial number

## ⑭ Type

- When the type column is blank, it indicates that the part is applicable to all types.
- As the type of the actual unit may differ from the "parts catalogue, type" please refer to "Models, types and applicable serial numbers" for confirmation.

## ⑮

- Parts enclosed within a dotted line are covered in a different block.

## ⑯

- A hollow arrow indicates the block No. for the parts enclosed within a dotted line .

## ⑰

- A solid arrow indicates the block No. the part in question is connected to.

### When the parts were revised



Be sure to check the serial number!!



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.
			BF	BFP	BF	BFP	BF	BFP	
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2	
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER							
		*NH8*.....DARK GRAY	1	1	1	1	1	1	
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1	
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1	
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1	
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1	1	
7	16617-ZW9-000	HOLDER, CABLE (###)	1	1	1	1	1	1	
	16617-ZW9-010		1	1	1	1	1	1	

The number has been used from the initial model without revision.

When shown at the left side, it is applicable to the models of No.1001801 and the subsequent numbers.

When shown at the right side, it is applicable to the models up to No.1001800.



• The parts listed with "###" at the end of the parts name have limited supply period (parts not for sale).

### Abbreviations used in the parts catalogue

• The following abbreviations are used in the parts name column.


A ..... Ampere	FR. ....Front
A.C. .... Alternating current	IN. ....Inlet
ASSY. .... Assembly	L (100L) .Link (100 Links)
AT. .... Automatic transmission	L. ....Left
C.D.I. .... Capacitive discharge ignition	MM .....Millimeter
COMP. ... Complete	MT. ....Manual Transmission
D.C. .... Direct current	P.T.O. ....Power take off
EX. .... Exhaust	R. ....Right
G.F.C.I ... Ground fault circuit interruptor	RR. ....Rear
HEX. .... Hexagonal	STD. ....Standard
H.S.T. .... Hydrostatic transmission	T (22T) ...Tooth (22 Teeth)
	V ..... Volt
	W .....Watt

# How to check the part block and serial numbers




②-B  
CARBURETOR  
IDENTIFICATION NUMBER  
GXV340A2

②-A  
CARBURETOR  
IDENTIFICATION NUMBER  
GXV340A2



②  
CARBURETOR  
IDENTIFICATION NUMBER  
GXV340A2  
(PROPANE)





- **Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.**

Model	Type	Parts catalogue type	Applicable engine serial No.	Applicable carburetor identification No.
GXV340A2	DAS	DAS	GJADA-1000001~	BE81H A
	DA2	DA2		
	DA23	DA23		
	DA33	DA33		
	DET3	DET3		
	DE33	DE33		
GXV340A2 (PROPANE)	DP23	DP23	GEAAA-1000001~	BEL6A C
GXV340A2	DX3	DX3	GJADA-1000001~	BE81H A

\* Of carburetor identification numbers, only the portions underlined in the example below are used for registration.

GXV340A2	BE 81H <u>A</u> KC +
	<u>A</u> <u>B</u>
GXV340A2 (PROPANE)	BEL6A <u>C</u> KC +

## Features of each type

- See the following table for the features of each type.

Specifications \ Model Type	GXV340A2							
	Standard equipment						Propane	Standard equipment
	DAS	DA2	DA23	DA33	DET3	DE33	DP23	DX3
Spark arrester								●
Fuel tank					●	●		●
Charge coil	●				●	●	●	
Starter motor	●				●	●		
Engine stop switch		●	●	●	●	●	●	●

## Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets ( ) underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name.  
(For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

### Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 9 5 0 0 1 - 7 5 0 0 1 - 5 0 M

Bulk part number:

Refers to the bulk part.

Marking code (fuel hose and general purpose hose)

Change code (Vinyl hose)

Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
  - 2: Red outside braid (3 mm inside dia. only)
  - 5: Black inside braid
  - 3: Red (3 mm inside dia. only)
  - 4: Ash gray with red stripe (3 mm inside dia. only)
  - 6: Black

- General hose
  - 1: Ash gray
  - 2: Ash gray
  - 3: Black
  - 5: Black

- Vinyl hose
  - 1: Clear
  - 2: Black
  - 3: Light red
  - 6: Light red
  - 7: Pale black

Lengths:

001: 1 m (standard)  
003: 3 m  
008: 8 m

Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm  
35: 3.5 mm  
45: 4.5 mm

50: 5.0 mm  
55: 5.3 mm, 5.5 mm  
65: 6.5 mm

70: 7.0 mm  
75: 7.3 mm, 7.5 mm  
80: 8.0 mm

11: 11 mm  
91: 12 (outside dia. 15) mm  
92: 12 (outside dia. 16) mm

12: 12 (outside dia. 17) mm  
14: 14 mm  
17: 17 mm

ID./OD. code: (vinyl hose)

01: ID. 2.9, OD. 6.8 mm  
03: ID. 3.0, OD. 6.0 mm  
05: ID. 3.5, OD. 6.5 mm  
07: ID. 4.0, OD. 7.0 mm  
08: ID. 4.5, OD. 6.5 mm  
09: ID. 4.5, OD. 8.0 mm

12: ID. 5.0, OD. 7.0 mm  
10: ID. 5.0, OD. 8.0 mm  
11: ID. 5.0, OD. 9.0 mm  
14: ID. 6.0, OD. 9.0 mm  
17: ID. 7.0, OD. 9.0 mm  
19: ID. 7.0, OD. 11.0 mm

21: ID. 8.0, OD. 9.0 mm  
23: ID. 8.0, OD. 12.0 mm  
25: ID. 9.0, OD. 11.0 mm  
27: ID. 9.0, OD. 13.0 mm  
33: ID. 10.0, OD. 14.0 mm  
36: ID. 11.0, OD. 13.0 mm

37: ID. 11.0, OD. 15.0 mm  
38: ID. 12.0, OD. 13.0 mm  
39: ID. 12.0, OD. 14.0 mm  
40: ID. 12.0, OD. 16.0 mm  
43: ID. 13.0, OD. 15.0 mm  
45: ID. 14.0, OD. 18.0 mm

50: ID. 16.0, OD. 19.0 mm  
55: ID. 17.5, OD. 20.5 mm  
60: ID. 22.0, OD. 27.0 mm

Hose type:

- 1: Fuel hose
- 3: Vinyl hose
- 5: General hose

⊙ **CAUTION:** It is **DANGEROUS** to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


# ENGINE GROUP

**B 9**

**E-2**

**C 1**

CYLINDER HEAD




Z1110-E0200

**E-3**

**C 2**

CYLINDER BARREL/OIL PAN




Z1110-E0300

**E-7**

**C 5**

CRANKSHAFT




Z1110-E0700

**E-8**

**C 6**

PISTON




Z1110-E0800

**E-9**

**C 7**

CAMSHAFT




Z1110-E0900

**E-11**

**C 8**

RECOIL STARTER(1)




Z1110-E1100

**E-11-1**

**C 9**

RECOIL STARTER(2)




Z1110-E1101

**E-12**

**C10**

FAN COVER




Z1110-E1200

**E-14**

**C11**

CARBURETOR(1)



Z1110-E1400

**2**


# ENGINE GROUP

**B10**

**E-14-1**

**C13**


CARBURETOR(2)



**E-15**

**C14**


AIR CLEANER(1)



**E-15-1**

**C15**


AIR CLEANER(2)



**E-16**

**C16**


MUFFLER(1)



**E-16-1**

**D 1**


MUFFLER(2)



**E-17**

**D 2**


FUEL TANK



**E-19**

**D 3**


FLYWHEEL



**E-20**

**D 4**


IGNITION COIL



**E-21**

**D 5**

STARTER MOTOR




# ENGINE GROUP

**B11**

**E-22**

**D 6**

CONTROL




Z1110-E2200

**E-28**

**D 8**

LABEL(1)




Z1110-E2800

**E-28-1**

**D 9**

LABEL(2)




Z1110-E2801

**E-29**

**D10**

TOOL




Z1110-E2900

**EOP-1**


**D11**

GASKET KIT




HENG-X0003

**2**



F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	12200-Z1E-405	HEAD COMP., CYLINDER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
	12200-Z1E-406	.....	1	-----	DP23
2	12204-ZE2-306	GUIDE, IN. VALVE (O.S.) .....	(1)		
3	12205-ZE2-305	GUIDE, EX. VALVE (O.S.) .....	(1)		
4	12216-ZE2-300	CLIP, VALVE GUIDE .....	2		
5	12251-ZE9-600	GASKET, CYLINDER HEAD .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
	12251-ZE9-900	.....	1	-----	DP23
6	12310-ZE8-000	COVER, HEAD .....	1		
7	12391-ZE8-000	PACKING, HEAD COVER .....	1		
8	18345-ZF5-020	COVER, UNDER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
9	18347-ZE8-000	STAY COMP., UNDER COVER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
10	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	3	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
11	90014-ZE8-000	BOLT, HEAD COVER .....	1		
12	90042-ZE8-000	BOLT, STUD, 8X131.5 .....	2		
13	90441-ZE2-010	WASHER COMP., HEAD COVER ....	1		
14	92900-08032-0B	BOLT, STUD, 8X32 .....	2		
15	94301-12200	DOWEL PIN, 12X20 .....	2		
16	95701-06012-00	BOLT, FLANGE, 6X12 .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
17	95701-10080-00	BOLT, FLANGE, 10X80 .....	4		
18	98079-55846	PLUG, SPARK (BPR5ES) (NGK) ...	1		




Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	11300-Z1E-405	PAN ASSY., OIL .....	1	-----	DAS,DET3
	11300-Z1E-406	.....	1	-----	DA23
	11300-Z1E-407	.....	1	-----	DE33,DX3
	11300-Z1E-408	.....	1	-----	DA2,DA33,DP23
2	11381-ZE9-801	PACKING, OIL PAN .....	1		
3	12000-Z1F-405	BARREL ASSY., CYLINDER .....	1		
4	12315-ZF5-000	TUBE, BREATHER .....	1		
5	12370-ZF5-000	CAP, BREATHER CHAMBER .....	1		
6	12372-ZE2-300	VALVE, BREATHER .....	1		
7	12373-ZE8-000	PACKING, BREATHER CAP .....	1		
8	12375-ZE9-010	PLATE, ONE-WAY VALVE .....	1	-----	DA2,DA23,DA33,DP23
9	12376-ZE8-000	VALVE, ONE WAY .....	1	-----	DA2,DA23,DA33,DP23
10	15130-ZE8-000	COVER, OIL PUMP .....	1		
11	15131-ZE9-003	O-RING, PUMP COVER .....	1		
12	15330-ZE8-000	ROTOR COMP., INNER .....	1		
13	15332-891-003	ROTOR, OIL PUMP OUTER .....	1		
14	15334-ZE8-010	PLATE, OIL FILTER .....	1	-----	DAS,DET3,DE33,DX3
15	15334-ZE8-811	PLATE, OIL FILTER .....	1	-----	DA2,DA23,DA33,DP23
16	15335-ZE9-000	RUBBER, OIL RETURN .....	1		
17	15336-ZE8-000	STOPPER, OIL .....	1	-----	DA2,DA23,DA33,DP23
18	15337-ZE8-000	PLATE, OIL STOPPER .....	1	-----	DA2,DA23,DA33,DP23
19	15400-ZJ1-004	CARTRIDGE, OIL FILTER .....	1		
		(TOYO ROKI)	1	-----	DAS,DA23,DET3
20	15411-ZF5-W00	BASE, OIL FILTER .....	1	-----	DAS,DA23,DET3
21	15420-ZE8-000	PLATE COMP., SUCTION .....	1	-----	DA2,DA23,DA33,DP23






Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
22	15421-ZE9-003	SCREEN, OIL FILTER .....	1		
23	15600-ZF5-000	CAP ASSY., OIL FILLER .....	1		
24	15625-ZE8-000	PACKING, OIL FILLER CAP .....	1		
25	15630-ZE8-000	EXTENSION, OIL FILLER .....	1		
26	16510-ZE3-000	GOVERNOR ASSY. ....	1		
27	16511-ZE8-000	WEIGHT, GOVERNOR .....	3		
28	16512-ZE3-000	HOLDER, GOVERNOR WEIGHT .....	1		
29	16513-ZE2-000	PIN, GOVERNOR WEIGHT .....	3		
30	16531-Z0A-000	SLIDER, GOVERNOR .....	1		
31	16541-ZE8-010	SHAFT, GOVERNOR ARM .....	1		
32	17240-ZE6-000	COLLAR, EXTENSION .....	1		
33	35410-ZF5-013	SWITCH COMP., OIL LEVEL .....	1	-----	DA2,DA23,DA33,DP23
34	35419-ZF5-000	PROTECTOR, SWITCH .....	1	-----	DA2,DA23,DA33,DP23
35	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	2	-----	DAS,DET3,DE33,DX3
			4	-----	DA2,DA23,DA33,DP23
36	90014-ZE6-000	BOLT, FLANGE, 6X35 .....	1		
37	90018-PN3-000	HOLDER, OIL FILTER .....	1	-----	DAS,DA23,DET3
38	90121-952-000	BOLT, FLANGE, 6X25(CT200) ...	2	-----	DAS,DA23,DET3
39	90406-VM6-000	WASHER, THRUST, 8.1MM .....	1		
40	90602-ZE1-000	CLIP, GOVERNOR HOLDER .....	1		
41	90701-HC4-000	DOWEL PIN, 8X12 .....	2		
42	91001-ZF5-003	BEARING, RADIAL BALL, 6202 ..	2		
43	91201-Z1C-003	OIL SEAL, 35X52X8 .....	2		
44	91203-952-771	OIL SEAL, 8X14X5 .....	1		
45	91301-ZE9-003	O-RING, 22.5X2.2 .....	1		



Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
46	91302-ZE9-003	O-RING, 11.8X2.4 .....	1	-----	DA2,DA23,DA33,DP23
47	91302-ZL8-003	O-RING, 11.8X2.4 .....	1	-----	DAS,DA23,DET3
48	91303-HA0-004	O-RING, 11X1.9(NOK) .....	2	-----	DAS,DET3,DE33,DX3
49	91501-ZF5-000	COLLAR, OIL FILTER SETTING ..	1	-----	
50	92800-20000	BOLT, DRAIN PLUG, 20MM .....	1	-----	
51	94101-06800	WASHER, PLAIN, 6MM .....	1	-----	DA2,DA23,DA33,DP23,DX3
52	94103-06700	WASHER, PLAIN, 6MM .....	1	-----	
53	94109-20000	WASHER, DRAIN PLUG, 20MM ....	1	-----	
54	94251-10000	PIN, LOCK, 10MM .....	1	-----	
55	95701-06012-00	BOLT, FLANGE, 6X12 .....	3	-----	
56	95701-06016-00	BOLT, FLANGE, 6X16 .....	1	-----	DA2,DA23,DA33,DP23
57	95701-06025-00	BOLT, FLANGE, 6X25 .....	1	-----	
58	95701-08040-08	BOLT, FLANGE, 8X40 .....	6	-----	
59	95701-08060-08	BOLT, FLANGE, 8X60 .....	1	-----	
60	96100-62073-00	BEARING, RADIAL BALL, 6207 ..	2	-----	



FR.

Z1H0-E0700

Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV	340		
1	13310-Z1E-000	CRANKSHAFT COMP. ....	1			
2	13351-ZE9-603	WEIGHT A, BALANCER .....	1			
3	13356-ZE9-604	WEIGHT B, BALANCER .....	1			
4	90417-HA0-000	WASHER, THRUST, 15MM .....	2			
5	90741-ZE2-000	KEY, SPECIAL WOODRUFF, 25X18	1			


E-8

## PISTON

C 6

Service item


F.R.T.



Z1H0-E0800


Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	13010-Z1F-800	RING SET, PISTON (STD.) .....	1		
	13011-Z1F-800	RING SET, PISTON (0.25) .....	(1)		
	13012-Z1F-800	RING SET, PISTON (0.50) .....	(1)		
	13013-Z1F-800	RING SET, PISTON (0.75) .....	(1)		
2	13101-ZE3-W00	PISTON (STD.) .....	1		
	13102-ZE3-W00	PISTON (0.25) .....	(1)		
	13103-ZE3-W00	PISTON (0.50) .....	(1)		
	13104-ZE3-W00	PISTON (0.75) .....	(1)		
3	13111-ZE3-000	PIN, PISTON .....	1		
4	13200-Z1E-000	ROD ASSY., CONNECTING .....	1		
	13200-Z1E-305	ROD ASSY., CONNECTING (0.25 UNDER SIZE) .....	(1)		
5	90001-ZE8-000	BOLT, CONNECTING ROD .....	2		
6	90601-ZE3-000	CLIP, PISTON PIN, 20MM .....	2		

2



F.R.T.

2




Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	28400-ZE3-W01ZB	STARTER ASSY., RECOIL	1	-----	DAS,DA33
	*NH1*.....	BLACK	1	-----	DA2,DA23,DA33,DET3,DE33,DX3
2	28400-ZE3-W01ZP	*R280*.....	1	-----	DA2,DA23,DA33,DET3,DE33,DX3
	*NH1*.....	POWER RED	1	-----	DAS,DA33
3	28410-ZE3-W01ZB	CASE COMP., RECOIL STARTER	1	-----	DA2,DA23,DA33,DET3,DE33,DX3
	*NH1*.....	BLACK	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
	*R280*.....	POWER RED	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
4	28421-ZE3-W01	PULLEY, RECOIL STARTER	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
5	28422-ZE2-W01	RATCHET, STARTER	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
6	28441-ZE2-W01	SPRING, FRICTION	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
7	28442-ZE2-W01	SPRING, STARTER RETURN	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
8	28443-ZE2-W01	SPRING, RATCHET	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
9	28444-ZE2-W01	RETAINER, SPRING	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
10	28461-ZE2-W02	GRIP, STARTER	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
11	28462-ZE3-W01	ROPE, RECOIL STARTER	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
12	90004-ZE2-W01	SCREW, CENTER	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
	94050-06000	NUT, FLANGE, 6MM	4	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3

# E-11-1

# RECOIL STARTER(2)

C 9




Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	17219-ZE8-900	FILTER, AIR .....	1	-----	DP23
2	28400-ZE8-821ZC	STARTER ASSY., RECOIL *R280*.....POWER RED	1	-----	DP23
3	28410-ZE8-821ZC	CASE COMP., RECOIL STARTER *R280*.....POWER RED	1	-----	DP23
4	28421-ZE8-821	PULLEY, RECOIL STARTER .....	1	-----	DP23
5	28422-ZE2-W01	RATCHET, STARTER .....	2	-----	DP23
6	28441-ZE2-W01	SPRING, FRICTION .....	1	-----	DP23
7	28442-ZE2-W01	SPRING, STARTER RETURN .....	1	-----	DP23
8	28443-ZE2-W01	SPRING, RATCHET .....	2	-----	DP23
9	28444-ZE2-W01	RETAINER, SPRING .....	1	-----	DP23
10	28461-ZE2-W02	GRIP, STARTER .....	1	-----	DP23
11	28462-ZE2-W01	ROPE, RECOIL STARTER .....	1	-----	DP23
12	90004-ZE2-W01	SCREW, CENTER .....	1	-----	DP23
13	96001-06010-00	BOLT, FLANGE, 6X10 .....	3	-----	DP23



Service item

F.R.T.



Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	19610-ZF5-V11ZA	COVER COMP., FAN	1	-----	-----
	*NH1*	.....BLACK	1	-----	DAS
	19610-ZF5-V11ZC	*R280*	1	-----	DET3,DE33
	19610-ZF5-V21ZA	*NH1*	1	-----	DA33
	19610-ZF5-V21ZC	*R280*	1	-----	DA2,DA23,DA33,DX3
2	19610-ZF5-801ZE	COVER COMP., FAN	1	-----	-----
	*R280*	.....POWER RED	1	-----	DP23
3	19611-ZE8-901	PLATE COMP., SIDE	1	-----	DP23
4	19612-ZF5-010	PLATE, SIDE	1	-----	DA2,DA23,DA33,DX3
5	19617-ZF5-V00	BRACKET, FAN COVER	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
6	31255-ZE8-901	STAY COMP., STARTER	1	-----	DP23
7	90013-883-000	BOLT, FLANGE, 6X12(CT200)	1	-----	DP23
8	90029-888-000	BOLT, FLANGE, 6X16(CT200)	4	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
9	91501-ZF5-V00	COLLAR, FAN COVER	4	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
10	95701-08016-00	BOLT, FLANGE, 8X16	2	-----	DP23
11	95701-08020-08	BOLT, FLANGE, 8X20	2	-----	DA2,DA23,DA33,DX3
12	95801-08028-00	BOLT, FLANGE, 8X28	2	-----	DP23





Z1H0-E1400

Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	16010-ZE2-015	GASKET SET .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
2	16011-ZA0-931	VALVE SET, FLOAT .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
3	16013-Z1C-003	FLOAT SET .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
4	16015-ZE8-005	CHAMBER SET, FLOAT .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
5	16016-ZH7-W01	SCREW SET, PILOT .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
6	16024-ZE1-811	SCREW SET, DRAIN .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
7	16028-ZE0-005	SCREW SET .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
8	16100-Z1F-W01	CARBURETOR ASSY. (BE81H A) ..	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
9	16124-ZE0-005	SCREW, THROTTLE STOP .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
10	16148-141-881	CAP, CHOKE DUST .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
11	16166-ZE9-W01	NOZZLE, MAIN .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
12	16172-ZE3-W10	COLLAR, SETTING .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
13	16199-ZE8-000	TUBE, AIR VENT (75MM) .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
14	16211-ZE9-601	INSULATOR, CARBURETOR .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
15	16220-ZA0-702	SPACER COMP., CARBURETOR ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
16	16221-ZE3-800	PACKING, CARBURETOR .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
17	16223-ZE9-800	PACKING, INSULATOR .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
18	16953-ZE1-712	LEVER, COCK .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
19	16954-ZE1-812	PLATE, LEVER SETTING .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
20	16956-ZE1-811	SPRING, COCK LEVER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
21	16957-ZE1-812	PACKING, FUEL COCK .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
22	93500-03006-1H	SCREW, PAN, 3X6 .....	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
23	95002-02080	CLIP, TUBE (B8) .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
24	99101-ZH8-0880	JET, MAIN, #88 .....	(1)	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
	99101-ZH8-0900	JET, MAIN, #90 .....	(1)	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3

E-14


## CARBURETOR(1)

C12



Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV	A2		
24)	99101-ZH8-0920	JET, MAIN, #92 .....	1	-----	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
25	99204-ZE0-0380	JET SET, PILOT, #38 .....	1	-----	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3


2



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV 340 A2			
1	16100-ZE9-V43	CARBURETOR ASSY. (BEL6A C) ..	1	-----	-----	DP23
2	16124-ZE0-005	SCREW, THROTTLE STOP .....	1	-----	-----	DP23
3	16148-141-881	CAP, CHOKE DUST .....	1	-----	-----	DP23
4	16172-ZE3-W10	COLLAR, SETTING .....	1	-----	-----	DP23
5	16211-ZE9-601	INSULATOR, CARBURETOR .....	1	-----	-----	DP23
6	16220-ZA0-702	SPACER COMP., CARBURETOR ....	1	-----	-----	DP23
7	16221-ZE3-800	PACKING, CARBURETOR .....	1	-----	-----	DP23
8	16223-ZE9-800	PACKING, INSULATOR .....	1	-----	-----	DP23
9	36135-PH3-004	VALVE, DASHPOT CHECK .....	(1)	-----	-----	DP23
10	99104-ZE9-0450	JET, PILOT, #45 .....	1	-----	-----	DP23



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	17211-ZF5-V01	ELEMENT, AIR CLEANER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
2	17218-ZF5-V00	FILTER, OUTER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
3	17231-ZF5-V00	COVER, AIR CLEANER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
4	17410-ZF5-V00	ELBOW COMP., AIR CLEANER ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
5	90014-ZE6-000	BOLT, FLANGE, 6X35 .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
6	90325-044-000	NUT, TOOL BOX SETTING .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
7	91502-ZF5-V00	COLLAR, AIR CLEANER .....	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
8	91503-ZF5-V00	COLLAR, AIR CLEANER .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
9	94050-06000	NUT, FLANGE, 6MM .....	2	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3

**C15**




Z1H0-E1501

---

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV 340 A2			
1	16271-ZE8-000	PACKING, ELBOW .....	1	-----	-----	DP23
2	17210-ZF5-010	ELEMENT COMP., AIR CLEANER ..	1	-----	-----	DP23
3	17218-ZF5-000	FILTER, OUTER .....	1	-----	-----	DP23
4	17230-ZE8-900	COVER, AIR CLEANER (DUAL) ...	1	-----	-----	DP23
5	17232-891-000	GROMMET, AIR CLEANER .....	1	-----	-----	DP23
6	17238-ZE1-000	COLLAR, AIR CLEANER .....	1	-----	-----	DP23
7	17238-ZE2-310	COLLAR, AIR CLEANER .....	2	-----	-----	DP23
8	17410-ZE8-900	ELBOW COMP., AIR CLEANER ....	1	-----	-----	DP23
9	90014-ZE6-000	BOLT, FLANGE, 6X35 .....	1	-----	-----	DP23
10	90325-044-000	NUT, TOOL BOX SETTING .....	2	-----	-----	DP23
11	94050-06000	NUT, FLANGE, 6MM .....	2	-----	-----	DP23




Z1H0-E1600

Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	18310-Z1E-000	MUFFLER COMP. ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
2	18316-ZF5-V00	SEPARATOR, MUFFLER ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
3	18318-ZE8-000	STAY COMP., MUFFLER ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
4	18321-ZF5-000	PROTECTOR, MUFFLER ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
5	18331-ZE2-810	CAP, MUFFLER ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
6	18331-ZF5-000	PIPE, EX. ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
7	18333-ZE3-800	GASKET, EX. PIPE ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
8	18335-ZE8-000	ARRESTER, SPARK ....	1	-----	DX3
9	18382-ZE9-800	GASKET, EX. PIPE ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
10	90031-883-000	BOLT, FLANGE, 8X16 ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
11	90050-ZE1-000	SCREW, TAPPING, 5X8 ....	3	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
12	90055-ZE1-000	SCREW, TAPPING, 4X6 ....	3	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
13	92900-08060-1B	BOLT, STUD, 8X60 ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
14	92900-08070-1B	BOLT, STUD, 8X70 ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
15	93500-06006-0A	SCREW, PAN, 6X6 ....	3	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
16	94050-08000	NUT, FLANGE, 8MM ....	4	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
17	94101-06000	WASHER, PLAIN, 6MM ....	3	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
18	95701-08014-00	BOLT, FLANGE, 8X14 ....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3




Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV 340 A2			
1	18310-Z1E-900	MUFFLER COMP. ....	1	-----	-----	DP23
2	18318-ZE8-000	STAY COMP., MUFFLER .....	1	-----	-----	DP23
3	18320-Z1E-900	PROTECTOR COMP., MUFFLER ....	1	-----	-----	DP23
4	18325-ZE9-010	SEPARATOR, MUFFLER .....	1	-----	-----	DP23
5	18330-ZE9-000	PIPE, EX. ....	1	-----	-----	DP23
6	18333-ZE3-800	GASKET, EX. PIPE .....	1	-----	-----	DP23
7	18382-ZE9-800	GASKET, EX. PIPE .....	1	-----	-----	DP23
8	90031-883-000	BOLT, FLANGE, 8X16 .....	1	-----	-----	DP23
9	90050-ZE1-000	SCREW, TAPPING, 5X8 .....	4	-----	-----	DP23
10	92900-08060-1B	BOLT, STUD, 8X60 .....	1	-----	-----	DP23
11	92900-08070-1B	BOLT, STUD, 8X70 .....	1	-----	-----	DP23
12	93500-06006-0A	SCREW, PAN, 6X6 .....	3	-----	-----	DP23
13	94050-08000	NUT, FLANGE, 8MM .....	4	-----	-----	DP23
14	94101-06000	WASHER, PLAIN, 6MM .....	3	-----	-----	DP23
15	95701-08014-00	BOLT, FLANGE, 8X14 .....	1	-----	-----	DP23

Z1H0-E1601






Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	16910-ZE8-015	STRAINER COMP., FUEL .....	1	-----	DAS,DA2,DA23,DA33
2	16952-ZE6-000	STRAINER, FUEL .....	1	-----	DET3,DE33,DX3
3	17510-ZE9-000	TANK, FUEL .....	1	-----	DET3,DE33,DX3
4	17512-ZE9-000	TUBE, FUEL .....	1	-----	DET3,DE33,DX3
5	17516-ZE8-000	RUBBER B, TANK MOUNTING .....	1	-----	DET3,DE33,DX3
6	17516-896-700	RUBBER B, TANK MOUNTING .....	3	-----	DET3,DE33,DX3
7	17518-ZE8-000	COLLAR, TANK SETTING .....	2	-----	DET3,DE33,DX3
8	17620-ZE7-000	CAP ASSY., FUEL TANK .....	1	-----	DET3,DE33,DX3
9	17621-ZE6-000	BODY, FUEL CAP .....	1	-----	DET3,DE33,DX3
10	17622-888-010	SPONGE, FUEL CAP BREATHER ...	1	-----	DET3,DE33,DX3
11	17624-ZE7-000	PACKING, FUEL CAP .....	1	-----	DET3,DE33,DX3
12	90455-896-700	WASHER, TANK MOUNTING .....	4	-----	DET3,DE33,DX3
13	90471-SB0-000	WASHER, PLAIN, 8MM .....	2	-----	DET3,DE33,DX3
14	95001-45230-50	HOSE, FUEL, 4.5X230 (95001-45001-50M)	1	-----	DAS
	95001-45360-20	HOSE, FUEL, 4.5X360 (95001-45001-50M)	1	-----	DA2,DA23,DA33
15	95002-02080	CLIP, TUBE (B8) .....	1	-----	DET3,DE33,DX3
16	95002-40850-08	CLAMP, TUBE (D8.5) .....	2	-----	DAS,DA2,DA23,DA33
17	95002-70000	CLIP, TUBE (C11) .....	1	-----	DET3,DE33,DX3
18	95701-08095-00	BOLT, FLANGE, 8X95 .....	2	-----	DET3,DE33,DX3






Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	19511-ZE9-010	FAN, COOLING .....	1		
2	28450-ZE9-004	PULLEY COMP., STARTER (SCREEN GRID)	1	-----	DAS, DA2, DA23, DA33, DET3, DE33, DX3
3	28451-ZE2-W01	PULLEY, STARTER .....	1	-----	DP23
4	31100-ZE9-020	FLYWHEEL COMP. ....	1	-----	DA2, DA23, DA33, DX3
5	31100-ZE9-804	FLYWHEEL COMP. (SEL-4POLE) ..	1	-----	DP23
6	31110-ZF5-L32	FLYWHEEL COMP. (SEL-4POLE) ..	1	-----	DAS, DET3, DE33
7	31510-ZE8-901	COIL ASSY., CHARGE .....	1	-----	DP23
	31630-ZF5-003	.....	1	-----	DAS, DET3, DE33
8	46391-VM0-003	CLIP, BRAKE PIPE (A) .....	1	-----	DAS, DET3, DE33
9	90015-883-000	BOLT, FLANGE, 6X28 .....	2	-----	DAS, DET3, DE33, DP23
10	90201-ZE3-V00	NUT, SPECIAL, 16MM .....	1	-----	DAS, DA2, DA23, DA33, DET3, DE33, DX3
	90201-ZE3-790	.....	1	-----	DP23

Service item


F.R.T.



Z1H0-E2000

FR.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	17239-ZE8-700	SPACER, AIR CLEANER ELBOW ...	1	-----	DP23
2	19613-ZA8-000	GROMMET, CORD .....	1	-----	DP23
3	30500-Z1E-013	COIL ASSY., IGNITION .....	1		
4	30700-ZF5-013	CAP ASSY., NOISE SUPPRESSOR ..	1		
5	31700-ZE8-003	RECTIFIER ASSY., SILICON ....	1	-----	DAS,DET3,DE33
	31700-ZE8-901	.....	1	-----	DP23
6	31717-ZF5-V00	BRACKET, RECTIFIER .....	1	-----	DAS,DET3,DE33
7	32161-404-610	BAND B1, WIRE .....	1	-----	DAS,DET3,DE33
8	36101-ZE8-000	CORD, STOP SWITCH .....	1	-----	DX3
9	36101-ZE8-810	CORD, STOP SWITCH .....	1	-----	DAS,DA2,DA23,DA33,DET3,DE33,DP23
10	36103-ZE1-000	HOLDER, STOP SWITCH CORD ....	1	-----	DA2,DA23,DA33,DP23
	51125-ZOL-003	HOLDER, WIRE (FASTEX) .....	1	-----	DA2,DA23,DA33,DP23
11	46391-VM0-003	CLIP, BRAKE PIPE (A) .....	2		
12	80101-166-000	GROMMET, WIRE CORD .....	1		
13	90015-883-000	BOLT, FLANGE, 6X28 .....	2		
14	90684-ZA0-601	CLIP, HARNESS .....	1	-----	DP23
15	95701-06032-00	BOLT, FLANGE, 6X32 .....	1	-----	DAS,DET3,DE33
	95701-06040-00	BOLT, FLANGE, 6X40 .....	1	-----	DP23



Z1H0-E2100


Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	31200-ZF5-L32	MOTOR ASSY., STARTER .....	1	-----	DAS,DET3,DE33
2	31206-ZF5-L31	DRIVE ASSY. ....	1	-----	DAS,DET3,DE33
3	31216-ZJ1-004	YOKE COMP. ....	1	-----	DAS,DET3,DE33
4	31217-ZF5-L31	ARMATURE COMP. ....	1	-----	DAS,DET3,DE33
5	31225-ZF5-L31	STOPPER SET, PINION .....	1	-----	DAS,DET3,DE33
6	31226-ZF5-L31	BRUSH SET .....	1	-----	DAS,DET3,DE33
7	31231-ZJ1-004	HOLDER COMP., BRUSH .....	1	-----	DAS,DET3,DE33
8	31237-ZJ1-004	NUT SET, TERMINAL .....	1	-----	DAS,DET3,DE33
9	31261-ZF5-L31	BOLT, THROUGH .....	2	-----	DAS,DET3,DE33
10	32402-ZF5-V00	CORD, MAGNET SWITCH .....	1	-----	DAS,DET3,DE33
11	32411-ZV4-811	COVER, STARTER TERMINAL .....	1	-----	DAS,DET3,DE33
12	32412-ZV4-811	COVER, MAGNETIC SWITCH .....	1	-----	DAS,DET3,DE33
13	35850-ZF5-V01	SWITCH ASSY., STARTER MAGNETIC .....	1	-----	DAS,DET3,DE33
14	90407-ZF5-L31	WASHER, THRUST .....	1	-----	DAS,DET3,DE33
15	91504-ZF5-V00	COLLAR, DISTANCE .....	2	-----	DAS,DET3,DE33
16	94070-06080	NUT-WASHER, 6MM .....	2	-----	DAS,DET3,DE33
17	94301-10120	DOWEL PIN, 10X12 .....	2	-----	DAS,DET3,DE33
18	95701-08035-00	BOLT, FLANGE, 8X35 .....	2	-----	DAS,DET3,DE33
19	96001-06025-00	BOLT, FLANGE, 6X25 .....	2	-----	DAS,DET3,DE33


Service item

F.R.T.



Z1H0-E2200

Ref. No.	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalogue code
1	16500-ZF5-U11	CONTROL ASSY. (AYP) .....	1	-----	DAS
2	16500-ZF5-010	CONTROL ASSY. ....	1	-----	DET3,DE33,DX3
3	16500-ZF5-800	CONTROL ASSY. ....	1	-----	DA2,DA23,DA33,DP23
4	16551-ZF5-000	ARM, GOVERNOR .....	1		
5	16555-ZE9-000	ROD, GOVERNOR .....	1		
6	16556-ZE9-000	ROD, CHOKE .....	1		
7	16557-ZE8-810	ROD, JOINT .....	1		
8	16561-ZF5-000	SPRING, GOVERNOR .....	1		
9	16563-ZE8-000	SPRING, GOVERNOR PRIMARY .....	1		
10	16576-891-000	HOLDER, CABLE .....	1		
11	16584-883-300	SPRING, CONTROL ADJUSTING ...	1		
12	16592-732-700	SPRING, CABLE RETURN .....	1		
13	16619-ZF5-000	LEVER, CHOKE JOINT .....	1		
14	35330-ZG1-751	SWITCH ASSY., ENGINE .....	1	-----	DA2,DA23,DA33,DET3,DE33,DP23,DX3
15	35336-750-003	SWITCH SET, CLUTCH .....	1	-----	DA2,DA23,DA33,DET3,DE33,DP23,DX3
16	36100-ZE8-003	SWITCH ASSY., ENGINE STOP ...	1	-----	DA2,DA23,DA33,DET3,DE33,DP23,DX3
17	38400-ZE8-003	BUZZER ASSY. ....	1	-----	DA2,DA23,DA33,DP23
18	38401-ZF5-800	STAY, BUZZER .....	1	-----	DA2,DA23,DA33,DP23
19	38402-GC1-000	SUSPENSION, AUDIBLE PILOT ...	1	-----	DA2,DA23,DA33,DP23
20	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	1		
21	90015-ZE5-010	BOLT, GOVERNOR ARM .....	1		
22	90015-ZE8-000	BOLT, FLANGE, 6MM .....	1		
23	93500-05020-0A	SCREW, PAN, 5X20 .....	1		
24	90050-ZE1-000	SCREW, TAPPING, 5X8 .....	1	-----	DA2,DA23,DA33,DP23
25	90684-ZA0-601	CLIP, HARNESS .....	1	-----	DA2,DA23,DA33,DP23




Z1H0-E2200

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV	340		
			A2			
26	92301-05014-1A	BOLT, RECESSED, 5X14 .....	1	-----	-----	DAS,DET3,DE33,DX3
	92301-05016-0A	BOLT, RECESSED, 5X16 .....	1	-----	-----	DA2,DA23,DA33,DP23
27	93500-04014-0A	SCREW, PAN, 4X14 .....	1	-----	-----	DA2,DA23,DA33,DET3,DE33,DP23,DX3
28	94050-06000	NUT, FLANGE, 6MM .....	1	-----	-----	
29	94101-06800	WASHER, PLAIN, 6MM .....	1	-----	-----	
30	94111-04000	WASHER, SPRING, 4MM .....	1	-----	-----	DA2,DA23,DA33,DET3,DE33,DP23,DX3
31	94111-05000	WASHER, SPRING, 5MM .....	1	-----	-----	DA2,DA23,DA33,DP23

Service item

F.R.T.




Z1H0-E2800

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV	A2		
1	87101-ZE9-V01	EMBLEM, TOP COVER (11.0) ....	1	-----	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
2	87522-ZF5-V00	LABEL, CAUTION .....	1	-----	-----	DAS,DA2,DA23,DA33,DET3,DE33,DX3
3	87601-ZF5-T10	MARK, TYPE (DAS) .....	1	-----	-----	DAS
	87601-ZF5-V70	MARK, TYPE (DA2) .....	1	-----	-----	DA2
	87601-ZF5-W00	MARK, TYPE (DA33) .....	1	-----	-----	DA33
	87601-ZF5-W10	MARK, TYPE (DA23) .....	1	-----	-----	DA23
	87601-ZF5-W20	MARK, TYPE (DE33) .....	1	-----	-----	DE33
	87601-ZF5-W30	MARK, TYPE (DET3) .....	1	-----	-----	DET3
	87601-ZF5-850	MARK, TYPE (DX3) .....	1	-----	-----	DX3

Service item

F.R.T.



Z1H0-E2801

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV 340 A2			
1	87101-ZE9-V01	EMBLEM, TOP COVER (11.0) ....	1	-----	-----	DP23
2	87106-ZE9-V00	LABEL, FUEL CAUTION .....	1	-----	-----	DP23
3	87140-VA3-T01	LABEL, HONDA NAME .....	1	-----	-----	DP23
4	87167-ZE9-901	LABEL, MAINTENANCE CAUTION ..	1	-----	-----	DP23
5	87522-ZF5-V00	LABEL, CAUTION .....	1	-----	-----	DP23
6	87601-ZE9-V00	MARK, TYPE (DP23) .....	1	-----	-----	DP23


E-29

## TOOL

D10

Service item

F.R.T.



Z1H0-E2900

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GXV 340 A2		
1	99004-21002	WRENCH, BOX (P21) .....	1		

2




EOP-1

## GASKET KIT

D11

Service item

F.R.T.



HENG-X0003

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GXV	340		
			A2			
1	06111-ZE9-U11	GASKET KIT .....	1	-----	-----	DAS,DA23,DA33,DET3,DE33,DX3
	06111-ZE9-V01	.....	1	-----	-----	DA2
	06111-ZE9-901	.....	1	-----	-----	DP23

2

# PART NO. INDEX

E 1

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
06000				14711-ZE3-000	C7	18	8	16500-ZF5-010	D6	33	2	18320-Z1E-900	D1	28	3	31000			
06111-ZE9-901	D11	38	1	14711-ZE9-900	C7	18	8	16500-ZF5-800	D6	33	3	18321-ZF5-000	C16	27	4	31100-ZE9-020	D3	30	4
06111-ZE9-U11	D11	38	1	14721-ZE3-000	C7	18	9	16500-ZF5-U11	D6	33	1	18325-ZE9-010	D1	28	4	31100-ZE9-804	D3	30	5
06111-ZE9-V01	D11	38	1	14721-ZE9-900	C7	18	9	16510-ZE3-000	C3	14	26	18330-ZE9-000	D1	28	5	31110-ZF5-L32	D3	30	6
				14751-Z1C-000	C7	18	10	16511-ZE8-000	C3	14	27	18331-ZE2-810	C16	27	5	31200-ZF5-L32	D5	32	1
				14771-ZE2-000	C7	18	11	16512-ZE3-000	C3	14	28	18331-ZF5-000	C16	27	6	31206-ZF5-L31	D5	32	2
11000								16513-ZE2-000	C3	14	29	18333-ZE3-800	C16	27	7	31216-ZJ1-004	D5	32	3
11300-Z1E-405	C2	13	1	14773-ZE2-000	C7	18	12	16531-Z0A-000	C3	14	30		D1	28	6	31217-ZF5-L31	D5	32	4
11300-Z1E-406	C2	13	1	14775-ZE2-010	C7	18	13	16541-ZE8-010	C3	14	31	18335-ZE8-000	C16	27	8	31225-ZF5-L31	D5	32	5
11300-Z1E-407	C2	13	1	14781-ZE2-000	C7	18	14	16551-ZF5-000	D6	33	4	18345-ZF5-020	C1	12	8	31226-ZF5-L31	D5	32	6
11300-Z1E-408	C2	13	1	14791-ZE9-010	C7	18	15	16555-ZE9-000	D6	33	5	18347-ZE8-000	C1	12	9	31231-ZJ1-004	D5	32	7
11381-ZE9-801	C2	13	2					16556-ZE9-000	D6	33	6	18382-ZE9-800	C16	27	9	31237-ZJ1-004	D5	32	8
				15000				16557-ZE8-810	D6	33	7		D1	28	7	31255-ZE8-901	C10	21	6
								16561-ZF5-000	D6	33	8	19000				31261-ZF5-L31	D5	32	9
12000				15130-ZE8-000	C2	13	10	16563-ZE8-000	D6	33	9					31510-ZE8-901	D3	30	7
12000-Z1F-405	C2	13	3	15131-ZE9-003	C2	13	11	16576-891-000	D6	33	10	19511-ZE9-010	D3	30	1	31630-ZF5-003	D3	30	7
12200-Z1E-405	C1	12	1	15330-ZE8-000	C2	13	12	16584-883-300	D6	33	11	19610-ZF5-801ZE	C10	21	2	31700-ZE8-003	D4	31	5
12200-Z1E-406	C1	12	1	15332-891-003	C2	13	13	16592-732-700	D6	33	12	19610-ZF5-V11ZA	C10	21	1	31700-ZE8-901	D4	31	5
12204-ZE2-306	C1	12	2	15334-ZE8-010	C2	13	14	16619-ZF5-000	D6	33	13	19610-ZF5-V11ZC	C10	21	1	31717-ZF5-V00	D4	31	6
12205-ZE2-305	C1	12	3	15334-ZE8-811	C2	13	15	16910-ZE8-015	D2	29	1	19610-ZF5-V21ZA	C10	21	1				
12209-ZE8-003	C7	18	1	15335-ZE9-000	C2	13	16	16952-ZE6-000	D2	29	2	19610-ZF5-V21ZC	C10	21	1	32000			
12216-ZE2-300	C1	12	4	15336-ZE8-000	C2	13	17	16953-ZE1-712	C11	22	18	19611-ZE8-901	C10	21	3	32161-404-610	D4	31	7
12251-ZE9-600	C1	12	5	15337-ZE8-000	C2	13	18	16954-ZE1-812	C11	22	19	19612-ZF5-010	C10	21	4	32402-ZF5-V00	D5	32	10
12251-ZE9-900	C1	12	5	15400-ZJ1-004	C2	13	19	16956-ZE1-811	C11	22	20	19613-ZA8-000	D4	31	2	32411-ZV4-811	D5	32	11
12310-ZE8-000	C1	12	6	15411-ZF5-W00	C2	13	20	16957-ZE1-812	C11	22	21	19617-ZF5-V00	C10	21	5	32412-ZV4-811	D5	32	12
12315-ZF5-000	C2	13	4	15420-ZE8-000	C2	13	21												
12370-ZF5-000	C2	13	5	15421-ZE9-003	C3	14	22	17000				28000				35000			
12372-ZE2-300	C2	13	6	15600-ZF5-000	C3	14	23	17210-ZF5-010	C15	26	2	28400-ZE3-W01ZB	C8	19	1	35330-ZG1-751	D6	33	14
12373-ZE8-000	C2	13	7	15625-ZE8-000	C3	14	24	17211-ZF5-V01	C14	25	1	28400-ZE3-W01ZP	C8	19	1	35336-750-003	D6	33	15
12375-ZE9-010	C2	13	8	15630-ZE8-000	C3	14	25	17218-ZF5-000	C15	26	3	28400-ZE8-821ZC	C9	20	2	35410-ZF5-013	C3	14	33
12376-ZE8-000	C2	13	9	16000				17218-ZF5-V00	C14	25	2	28410-ZE3-W01ZB	C8	19	2	35419-ZF5-000	C3	14	34
12391-ZE8-000	C1	12	7	16010-ZE2-015	C11	22	1	17219-ZE8-900	C9	20	1	28410-ZE8-821ZC	C9	20	3	35850-ZF5-V01	D5	32	13
				16011-ZA0-931	C11	22	2	17230-ZE8-900	C15	26	4	28421-ZE3-W01	C8	19	3				
13000				16013-Z1C-003	C11	22	3	17231-ZF5-V00	C14	25	3	28421-ZE8-821	C9	20	4	36000			
13010-Z1F-800	C6	17	1	16015-ZE8-005	C11	22	4	17232-891-000	C15	26	5	28422-ZE2-W01	C8	19	4	36100-ZE8-003	D6	33	16
13011-Z1F-800	C6	17	1	16016-ZH7-W01	C11	22	5	17238-ZE1-000	C15	26	6		C9	20	5	36101-ZE8-000	D4	31	8
13012-Z1F-800	C6	17	1	16024-ZE1-811	C11	22	6	17238-ZE2-310	C15	26	7	28441-ZE2-W01	C8	19	5	36101-ZE8-810	D4	31	9
13013-Z1F-800	C6	17	1	16028-ZE0-005	C11	22	7	17239-ZE8-700	D4	31	1	28442-ZE2-W01	C8	19	6	36103-ZE1-000	D4	31	10
13101-ZE3-W00	C6	17	2	16100-Z1F-W01	C11	22	8	17240-ZE6-000	C3	14	32	28443-ZE2-W01	C8	19	7	36135-PH3-004	C13	24	9
13102-ZE3-W00	C6	17	2	16100-ZE9-V43	C13	24	1	17410-ZE8-900	C15	26	8		C9	20	6				
13103-ZE3-W00	C6	17	2	16124-ZE0-005	C11	22	9	17410-ZF5-V00	C14	25	4	28444-ZE2-W01	C8	19	8	38000			
13104-ZE3-W00	C6	17	2					17510-ZE9-000	D2	29	3	28450-ZE9-004	D3	30	2	38400-ZE8-003	D6	33	17
13111-ZE3-000	C6	17	3	16148-141-881	C11	22	10	17512-ZE9-000	D2	29	4	28451-ZE2-W01	D3	30	3	38401-ZF5-800	D6	33	18
13200-Z1E-000	C6	17	4					17516-896-700	D2	29	6	28461-ZE2-W02	C8	19	9	38402-GC1-000	D6	33	19
13200-Z1E-305	C6	17	4	16166-ZE9-W01	C11	22	11	17516-ZE8-000	D2	29	5		C9	20	10	46000			
13310-Z1E-000	C5	16	1	16172-ZE3-W10	C11	22	12	17518-ZE8-000	D2	29	7	28462-ZE2-W01	C9	20	11	46391-VM0-003	D3	30	8
13351-ZE9-603	C5	16	2					17620-ZE7-000	D2	29	8	28462-ZE3-W01	C8	19	10		D4	31	11
13356-ZE9-604	C5	16	3	16199-ZE8-000	C11	22	13	17621-ZE6-000	D2	29	9					51000			
				16211-ZE9-601	C11	22	14	17622-888-010	D2	29	10					51125-Z0L-003	D4	31	10
								17624-ZE7-000	D2	29	11								
14000																			
14100-ZE8-602	C7	18	2	16220-ZA0-702	C13	24	5	18000				30000							
14410-Z1C-000	C7	18	3					18310-Z1E-000	C16	27	1								
14431-ZE2-010	C7	18	4	16221-ZE3-800	C11	22	16	18310-Z1E-900	D1	28	1	30500-Z1E-013	D4	31	3				
14441-ZE2-000	C7	18	5					18316-ZF5-V00	C16	27	2	30700-ZF5-013	D4	31	4				
14451-ZE1-013	C7	18	6	16223-ZE9-800	C11	22	17	18318-ZE8-000	C16	27	3								
14568-ZE1-000	C7	18	7	16271-ZE8-000	C15	26	1		D1	28	2								

3

# PART NO. INDEX

E 2

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
80000				90455-896-700	D2	29	12	94111-05000	D7	34	31								
80101-166-000	D4	31	12	90471-SB0-000	D2	29	13	94251-10000	C4	15	54								
				90601-ZE3-000	C6	17	6	94301-10120	D5	32	17								
				90602-ZE1-000	C3	14	40	94301-12200	C1	12	15								
87000				90684-ZA0-601	D4	31	14												
					D6	33	25	95000											
87101-ZE9-V01	D8	35	1	90701-HC4-000	C3	14	41												
	D9	36	1	90741-ZE2-000	C5	16	5	95001-45230-50	D2	29	14								
87106-ZE9-V00	D9	36	2					95001-45360-20	D2	29	14								
87140-VA3-T01	D9	36	3	91000				95002-02080	C11	22	23								
87167-ZE9-901	D9	36	4						D2	29	15								
87522-ZF5-V00	D8	35	2	91001-ZF5-003	C3	14	42	95002-40850-08	D2	29	16								
	D9	36	5	91201-Z1C-003	C3	14	43	95002-70000	D2	29	17								
87601-ZE9-V00	D9	36	6	91203-952-771	C3	14	44	95701-06012-00	C1	12	16								
87601-ZF5-850	D8	35	3	91301-ZE9-003	C3	14	45		C4	15	55								
87601-ZF5-T10	D8	35	3	91302-ZE9-003	C4	15	46	95701-06016-00	C4	15	56								
87601-ZF5-V70	D8	35	3	91302-ZL8-003	C4	15	47	95701-06025-00	C4	15	57								
87601-ZF5-W00	D8	35	3	91303-HA0-004	C4	15	48	95701-06032-00	D4	31	15								
87601-ZF5-W10	D8	35	3	91501-ZF5-000	C4	15	49	95701-06040-00	D4	31	15								
87601-ZF5-W20	D8	35	3	91501-ZF5-V00	C10	21	9	95701-08014-00	C16	27	18								
87601-ZF5-W30	D8	35	3	91502-ZF5-V00	C14	25	7		D1	28	15								
				91503-ZF5-V00	C14	25	8	95701-08016-00	C10	21	10								
90000				91504-ZF5-V00	D5	32	15	95701-08020-08	C10	21	11								
								95701-08035-00	D5	32	18								
90001-ZE8-000	C6	17	5	92000				95701-08040-08	C4	15	58								
90004-ZE2-W01	C8	19	11					95701-08060-08	C4	15	59								
	C9	20	12	92301-05014-1A	D7	34	26	95701-08095-00	D2	29	18								
90012-ZE0-010	C7	18	16	92301-05016-0A	D7	34	26	95701-10080-00	C1	12	17								
90013-883-000	C1	12	10	92800-20000	C4	15	50	95801-08028-00	C10	21	12								
	C3	14	35	92900-08032-0B	C1	12	14												
	C10	21	7	92900-08060-1B	C16	27	13	96000											
	D6	33	20		D1	28	10												
90014-ZE6-000	C3	14	36	92900-08070-1B	C16	27	14	96001-06010-00	C9	20	13								
	C14	25	5		D1	28	11	96001-06025-00	D5	32	19								
	C15	26	9					96100-62073-00	C4	15	60								
90014-ZE8-000	C1	12	11	93000															
90015-883-000	D3	30	9					98000											
	D4	31	13	93500-03006-1H	C11	22	22												
90015-ZE5-010	D6	33	21	93500-04014-0A	D7	34	27	98079-55846	C1	12	18								
90015-ZE8-000	D6	33	22	93500-05020-0A	D6	33	23												
90018-PN3-000	C3	14	37	93500-06006-0A	C16	27	15	99000											
90029-888-000	C10	21	8		D1	28	12												
90031-883-000	C16	27	10					99004-21002	D10	37	1								
	D1	28	8	94000				99101-ZH8-0880	C11	22	24								
90042-ZE8-000	C1	12	12					99101-ZH8-0900	C11	22	24								
90050-ZE1-000	C16	27	11	94050-06000	C8	19	12	99101-ZH8-0920	C12	23	24								
	D1	28	9		C14	25	9	99104-ZE9-0450	C13	24	10								
	D6	33	24		C15	26	11	99204-ZE0-0380	C12	23	25								
90055-ZE1-000	C16	27	12		D7	34	28												
90121-952-000	C3	14	38	94050-08000	C16	27	16												
90201-ZE3-790	D3	30	10		D1	28	13												
90201-ZE3-V00	D3	30	10	94070-06080	D5	32	16												
90206-ZE1-000	C7	18	17	94101-06000	C16	27	17												
90325-044-000	C14	25	6		D1	28	14												
	C15	26	10	94101-06800	C4	15	51												
90406-VM6-000	C3	14	39		D7	34	29												
90407-ZF5-L31	D5	32	14	94103-06700	C4	15	52												
90417-HA0-000	C5	16	4	94109-20000	C4	15	53												
90441-ZE2-010	C1	12	13	94111-04000	D7	34	30												

# PART NAME INDEX

F 1

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
[ A ]				[ C ]				[ D ]			
ARMATURE COMP. ....	D5	32	4	BOLT, STUD, 8X70 .....	D1	28	11	COVER, MAGNETIC SWITCH			
ARM, GOVERNOR .....	D6	33	4	BOLT, THROUGH .....	D5	32	9	TERMINAL	D5	32	12
ARM, VALVE ROCKER .....	C7	18	4	BRACKET, FAN COVER .....	C10	21	5	COVER, OIL PUMP .....	C2	13	10
ARRESTER, SPARK .....	C16	27	8	BRACKET, RECTIFIER .....	D4	31	6	COVER, STARTER TERMINAL .....	D5	32	11
				BRUSH SET .....	D5	32	6	COVER, UNDER .....	C1	12	8
				Buzzer ASSY. ....	D6	33	17	CRANKSHAFT COMP. ....	C5	16	1
[ B ]				[ E ]				[ F ]			
BAND B1, WIRE .....	D4	31	7	CAMSHAFT ASSY. ....	C7	18	2	FAN, COOLING .....	D3	30	1
BARREL ASSY., CYLINDER .....	C2	13	3	CAP ASSY., FUEL TANK .....	D2	29	8	FILTER, AIR .....	C9	20	1
BASE, OIL FILTER .....	C2	13	20	CAP ASSY., NOISE SUPPRESSOR ...	D4	31	4	FILTER, OUTER .....	C14	25	2
BEARING, RADIAL BALL, 6202 ...	C3	14	42	CAP ASSY., OIL FILLER .....	C3	14	23		C15	26	3
BEARING, RADIAL BALL, 6207 ...	C4	15	60	CAP, BREATHER CHAMBER .....	C2	13	5	FLOAT SET .....	C11	22	3
BODY, FUEL CAP .....	D2	29	9	CAP, CHOKE DUST .....	C11	22	10	FLYWHEEL COMP. ....	D3	30	4
BOLT, CONNECTING ROD .....	C6	17	5		C13	24	3			5	
BOLT, DRAIN PLUG, 20MM .....	C4	15	50	CAP, MUFFLER .....	C16	27	5			6	
BOLT, FLANGE, 10X80 .....	C1	12	17	CARBURETOR ASSY. ....	C11	22	8				
BOLT, FLANGE, 6MM .....	D6	33	22		C13	24	1				
BOLT, FLANGE, 6X10 .....	C9	20	13	CARTRIDGE, OIL FILTER .....	C2	13	19				
BOLT, FLANGE, 6X12 .....	C1	12	10	CASE COMP., RECOIL STARTER ...	C8	19	2				
					C9	20	3				
	C3	14	35	CHAMBER SET, FLOAT .....	C11	22	4				
	C4	15	55	CLAMP, TUBE .....	D2	29	16				
	C10	21	7	CLIP, BRAKE PIPE .....	D3	30	8				
	D6	33	20		D4	31	11				
BOLT, FLANGE, 6X16 .....	C4	15	56	CLIP, GOVERNOR HOLDER .....	C3	14	40				
	C10	21	8	CLIP, HARNESS .....	D4	31	14				
BOLT, FLANGE, 6X25 .....	C3	14	38		D6	33	25				
	C4	15	57	CLIP, PISTON PIN, 20MM .....	C6	17	6				
	D5	32	19	CLIP, TUBE .....	C11	22	23				
BOLT, FLANGE, 6X28 .....	D3	30	9		D2	29	15				
	D4	31	13								
BOLT, FLANGE, 6X32 .....	D4	31	15	CLIP, VALVE GUIDE .....	C1	12	4				
BOLT, FLANGE, 6X35 .....	C3	14	36	COIL ASSY., CHARGE .....	D3	30	7				
	C14	25	5	COIL ASSY., IGNITION .....	D4	31	3				
	C15	26	9	COLLAR, AIR CLEANER .....	C14	25	7				
BOLT, FLANGE, 6X40 .....	D4	31	15								
BOLT, FLANGE, 8X14 .....	C16	27	18		C15	26	6	GASKET KIT .....	D11	38	1
	D1	28	15					GASKET SET .....	C11	22	1
BOLT, FLANGE, 8X16 .....	C10	21	10	COLLAR, DISTANCE .....	D5	32	15	GASKET, CYLINDER HEAD .....	C1	12	5
	C16	27	10	COLLAR, EXTENSION .....	C3	14	32	GASKET, EX. PIPE .....	C16	27	7
	D1	28	8	COLLAR, FAN COVER .....	C10	21	9				
BOLT, FLANGE, 8X20 .....	C10	21	11	COLLAR, OIL FILTER SETTING ...	C4	15	49				
BOLT, FLANGE, 8X28 .....	C10	21	12	COLLAR, SETTING .....	C11	22	12				
BOLT, FLANGE, 8X35 .....	D5	32	18		C13	24	4	GOVERNOR ASSY. ....	C3	14	26
BOLT, FLANGE, 8X40 .....	C4	15	58	COLLAR, TANK SETTING .....	D2	29	7	GRIP, STARTER .....	C8	19	9
BOLT, FLANGE, 8X60 .....	C4	15	59	CONTROL ASSY. ....	D6	33	1		C9	20	10
BOLT, FLANGE, 8X95 .....	D2	29	18					GROMMET, AIR CLEANER .....	C15	26	5
BOLT, GOVERNOR ARM .....	D6	33	21					GROMMET, CORD .....	D4	31	2
BOLT, HEAD COVER .....	C1	12	11	CORD, MAGNET SWITCH .....	D5	32	10	GROMMET, WIRE CORD .....	D4	31	12
BOLT, PIVOT, 8MM .....	C7	18	16	CORD, STOP SWITCH .....	D4	31	8	GUIDE, EX. VALVE .....	C1	12	3
BOLT, RECESSED, 5X14 .....	D7	34	26					GUIDE, IN. VALVE .....	C1	12	2
BOLT, RECESSED, 5X16 .....	D7	34	26	COVER COMP., FAN .....	C10	21	1	GUIDE, PUSH ROD .....	C7	18	15
BOLT, STUD, 8X131.5 .....	C1	12	12								
BOLT, STUD, 8X32 .....	C1	12	14	COVER, AIR CLEANER .....	C14	25	3				
BOLT, STUD, 8X60 .....	C16	27	13		C15	26	4				
	D1	28	10	COVER, HEAD .....	C1	12	6				
BOLT, STUD, 8X70 .....	C16	27	14								

# PART NAME INDEX

F 2

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
HOLDER, GOVERNOR WEIGHT .....	C3	14	28	[ O ]				ROD ASSY., CONNECTING.....	C6	17	4
HOLDER, OIL FILTER .....	C3	14	37					ROD, CHOKE .....	D6	33	6
HOLDER, STOP SWITCH CORD .....	D4	31	10	OIL SEAL, 35X52X8 .....	C3	14	43	ROD, GOVERNOR.....	D6	33	5
HOLDER, WIRE .....	D4	31	10	OIL SEAL, 8X14X5 .....	C3	14	44	ROD, JOINT .....	D6	33	7
HOSE, FUEL, 4.5X230 .....	D2	29	14	O-RING, 11X1.9 .....	C4	15	48	ROD, PUSH.....	C7	18	3
HOSE, FUEL, 4.5X360 .....	D2	29	14	O-RING, 11.8X2.4 .....	C4	15	46	ROPE, RECOIL STARTER.....	C8	19	10
[ I ]									C9	20	11
INSULATOR, CARBURETOR .....	C11	22	14	O-RING, 22.5X2.2 .....	C3	14	45	ROTATOR, VALVE .....	C7	18	14
	C13	24	5	O-RING, PUMP COVER .....	C2	13	11	ROTOR COMP., INNER.....	C2	13	12
[ J ]				[ P ]				ROTOR, OIL PUMP OUTER.....	C2	13	13
JET SET, PILOT, .....	C12	23	25	PACKING, BREATHER CAP .....	C2	13	7	RUBBER B, TANK MOUNTING.....	D2	29	5
JET, MAIN, .....	C11	22	24	PACKING, CARBURETOR .....	C11	22	16				6
	C12	23	24		C13	24	7	RUBBER, OIL RETURN.....	C2	13	16
JET, PILOT, .....	C13	24	10	PACKING, ELBOW .....	C15	26	1	[ S ]			
[ K ]				PACKING, FUEL CAP .....	D2	29	11	SCREEN, OIL FILTER .....	C3	14	22
KEY, SPECIAL WOODRUFF, 25X18 ..	C5	16	5	PACKING, FUEL COCK .....	C11	22	21	SCREW SET.....	C11	22	7
[ L ]				PACKING, HEAD COVER .....	C1	12	7	SCREW SET, DRAIN.....	C11	22	6
LABEL, CAUTION .....	D8	35	2	PACKING, INSULATOR .....	C11	22	17	SCREW SET, PILOT.....	C11	22	5
	D9	36	5		C13	24	8	SCREW, CENTER.....	C8	19	11
LABEL, FUEL CAUTION .....	D9	36	2	PACKING, OIL FILLER CAP .....	C3	14	24		C9	20	12
LABEL, HONDA NAME .....	D9	36	3	PACKING, OIL PAN .....	C2	13	2	SCREW, PAN, 3X6.....	C11	22	22
LABEL, MAINTENANCE CAUTION ...	D9	36	4	PAN ASSY., OIL .....	C2	13	1	SCREW, PAN, 4X14.....	D7	34	27
LEVER, CHOKE JOINT .....	D6	33	13	PIN, GOVERNOR WEIGHT .....	C3	14	29	SCREW, PAN, 5X20.....	D6	33	23
LEVER, COCK .....	C11	22	18	PIN, LOCK, 10MM .....	C4	15	54	SCREW, PAN, 6X6.....	C16	27	15
LIFTER, VALVE .....	C7	18	5	PIN, PISTON .....	C6	17	3		D1	28	12
[ M ]				PIPE, EX. ....	C16	27	6	SCREW, TAPPING, 4X6.....	C16	27	12
MARK, TYPE .....	D8	35	3		D1	28	5	SCREW, TAPPING, 5X8.....	C16	27	11
	D9	36	6	PISTON .....	C6	17	2		D1	28	9
MOTOR ASSY., STARTER .....	D5	32	1	PIVOT, ROCKER ARM .....	C7	18	6	SCREW, THROTTLE STOP.....	C11	22	9
MUFFLER COMP. ....	C16	27	1	PLATE COMP., SIDE .....	C10	21	3		C13	24	2
	D1	28	1	PLATE COMP., SUCTION .....	C2	13	21	SEAL, VALVE STEM.....	C7	18	1
[ N ]				PLATE, LEVER SETTING .....	C11	22	19	SEAT, VALVE SPRING .....	C7	18	13
NOZZLE, MAIN .....	C11	22	11	PLATE, OIL FILTER .....	C2	13	14	SEPARATOR, MUFFLER.....	C16	27	2
NUT-WASHER, 6MM .....	D5	32	16						D1	28	4
NUT SET, TERMINAL .....	D5	32	8	PLATE, OIL STOPPER .....	C2	13	18	SHAFT, GOVERNOR ARM.....	C3	14	31
NUT, FLANGE, 6MM .....	C8	19	12	PLATE, ONE-WAY VALVE .....	C2	13	8	SLIDER, GOVERNOR.....	C3	14	30
	C14	25	9	PLATE, SIDE .....	C10	21	4	SPACER COMP., CARBURETOR.....	C11	22	15
	C15	26	11	PLUG, SPARK .....	C1	12	18		C13	24	6
NUT, FLANGE, 8MM .....	D7	34	28	PROTECTOR COMP., MUFFLER .....	D1	28	3	SPACER, AIR CLEANER ELBOW.....	D4	31	1
	D1	28	13	PROTECTOR, MUFFLER .....	C16	27	4	SPONGE, FUEL CAP BREATHER.....	D2	29	10
NUT, PIVOT ADJUSTING .....	C7	18	17	PROTECTOR, SWITCH .....	C3	14	34	SPRING, CABLE RETURN.....	D6	33	12
NUT, SPECIAL, 16MM .....	D3	30	10	PULLEY COMP., STARTER .....	D3	30	2	SPRING, COCK LEVER.....	C11	22	20
NUT, TOOL BOX SETTING .....	C14	25	6	PULLEY, RECOIL STARTER .....	C8	19	3	SPRING, CONTROL ADJUSTING.....	D6	33	11
	C15	26	10		C9	20	4	SPRING, FRICTION.....	C8	19	5
				[ R ]					C9	20	6
				RATCHET, STARTER .....	C8	19	4	SPRING, GOVERNOR.....	D6	33	8
					C9	20	5	SPRING, GOVERNOR PRIMARY.....	D6	33	9
				RECTIFIER ASSY., SILICON .....	D4	31	5	SPRING, RATCHET.....	C8	19	7
				RETAINER, EX. VALVE SPRING ....	C7	18	12		C9	20	8
				RETAINER, IN. VALVE SPRING ....	C7	18	11	SPRING, STARTER RETURN.....	C8	19	6
									C9	20	7
				RETAINER, SPRING .....	C8	19	8	SPRING, VALVE.....	C7	18	10
					C9	20	9	SPRING, WEIGHT RETURN.....	C7	18	7
				RING SET, PISTON .....	C6	17	1	STARTER ASSY., RECOIL.....	C8	19	1
									C9	20	2
								STAY COMP., MUFFLER.....	C16	27	3

# PART NAME INDEX

F 3

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
STAY COMP., MUFFLER .....	D1	28	2								
STAY COMP., STARTER .....	C10	21	6								
STAY COMP., UNDER COVER .....	C1	12	9								
STAY, BUZZER .....	D6	33	18								
STOPPER SET, PINION .....	D5	32	5								
STOPPER, OIL .....	C2	13	17								
STRAINER COMP., FUEL .....	D2	29	1								
STRAINER, FUEL .....	D2	29	2								
SUSPENSION, AUDIBLE PILOT ....	D6	33	19								
SWITCH ASSY., ENGINE .....	D6	33	14								
SWITCH ASSY., ENGINE STOP ....	D6	33	16								
SWITCH ASSY., STARTER MAGNETIC	D5	32	13								
SWITCH COMP., OIL LEVEL .....	C3	14	33								
SWITCH SET, CLUTCH .....	D6	33	15								
[ T ]											
TANK, FUEL .....	D2	29	3								
TUBE, AIR VENT .....	C11	22	13								
TUBE, BREATHER .....	C2	13	4								
TUBE, FUEL .....	D2	29	4								
[ V ]											
VALVE SET, FLOAT .....	C11	22	2								
VALVE, BREATHER .....	C2	13	6								
VALVE, DASHPOT CHECK .....	C13	24	9								
VALVE, EX. ....	C7	18	9								
VALVE, IN. ....	C7	18	8								
VALVE, ONE WAY .....	C2	13	9								
[ W ]											
WASHER COMP., HEAD COVER .....	C1	12	13								
WASHER, DRAIN PLUG, 20MM .....	C4	15	53								
WASHER, PLAIN, 6MM .....	C4	15	51								
			52								
	C16	27	17								
	D1	28	14								
	D7	34	29								
WASHER, PLAIN, 8MM .....	D2	29	13								
WASHER, SPRING, 4MM .....	D7	34	30								
WASHER, SPRING, 5MM .....	D7	34	31								
WASHER, TANK MOUNTING .....	D2	29	12								
WASHER, THRUST .....	D5	32	14								
WASHER, THRUST, 15MM .....	C5	16	4								
WASHER, THRUST, 8.1MM .....	C3	14	39								
WEIGHT A, BALANCER .....	C5	16	2								
WEIGHT B, BALANCER .....	C5	16	3								
WEIGHT, GOVERNOR .....	C3	14	27								
WRENCH, BOX .....	D10	37	1								
[ Y ]											
YOKE COMP. ....	D5	32	3								

---

**1**

**FOREWORD INDEX**

---

**2**

**ENGINE GROUP**

---

**3**

**PART NUMBER INDEX**

---

**4**

**PART NAME INDEX**

---





July 22, 2007



# PARTS CATALOG NEWS

Honda Motor Co., Ltd. Service Division

## PARTS CATALOG - CORRECTED

Printed in Japan

CODE NO.	14Z1H501
PARTS CATALOG NEWS	GXV340A2 GXV340A2 (PROPANE ENGINE)
NEWS NO.	001

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY GXV 340 A2	Serial No.	Parts catalog code
E-7	1	E	13310-Z1E-000	*PARTS NO. DELETION			
		D	13310-ZF5-040	CRANKSHAFT COMP. ....	1		

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION  
T:APPLICATION CORRECTION Z:REMARKS CHANGE