


# Isolated Constant -Current-Source 1 $\mu\text{A}$ to 4095 $\mu\text{A}$



pin\_EB: Base to Gnds, Emitter to Iconst

pin\_CV\_SW: Switch from const.Current(I) to const.Voltage(U) for Fets