

## REMOVAL/INSTALLATION

Support the motorcycle using a safety stand or hoist, and raise the rear wheel off the ground.  
Remove the cushion connecting rod nut (rear side) [1] and cushion connecting rod bolt (rear side) [2].  
Remove the shock absorber lower nut [3] and shock absorber lower bolt [4].  
Remove the shock absorber upper nut [5] and shock absorber upper bolt [6].  
Remove the shock absorber [7] downward.

**NOTE:**

- Lift the swingarm [8] and remove the shock absorber while turning it.

Installation is in the reverse order of removal.

**TORQUE:**

Shock absorber upper nut:
54 N·m (5.5 kgf·m, 40 lbf·ft)
Shock absorber lower nut:
44 N·m (4.5 kgf·m, 32 lbf·ft)
Cushion connecting rod nut (rear side):
54 N·m (5.5 kgf·m, 40 lbf·ft)

**NOTE:**

- Install the bolts from the left side.

