

Steer-by-Wire bicycle Documentation

Simonas Draukšas

April 2022

Contents

1	Electronics box at the rear of the bicycle	2
1.1	Teensy	2
1.1.1	Teensy 3.6	2
1.1.2	Teensy 3.6 Pinout	2
1.1.3	Teensy 4.1	3
1.2	Microcontroller Board	3
1.2.1	Board's Pinout	3
1.3	Power Board	5
1.3.1	Board's Pinout	5

Chapter 1

Electronics box at the rear of the bicycle

1.1 Teensy

1.1.1 Teensy 3.6

The bicycle originally featured a Teensy 3.6 installed at the very back of the electronics box. This Teensy contains the code necessary to control the handlebars and the fork. It runs a PD controller implemented by Georgios Dialynas, which runs at 1000 Hz and makes the handlebar angle follow the fork angle, and vice-versa. The code can be found on [GitHub/gdialynas/Steer-by-wire-bicycle](https://github.com/gdialynas/Steer-by-wire-bicycle).

1.1.2 Teensy 3.6 Pinout

The following pins are used on Teensy 3.6, together with their functions and requirements:

- Pins 2 and 3 – Used for the rear wheel encoder. Both pins need to be Digital with Interrupt capabilities (all digital pins on Teensy 3.6).
- Pin 8 – Used to send PWM signal to the handlebar motor. Pin needs to be PWM capable.
- Pin 9 – Used to send PWM signal to the fork motor. Pin needs to be PWM capable.
- Pin 10 – Used as a Chip Select (CS) pin for the SPI communication with the IMU. Needs to be a Digital pin.
- Pin 11 – Used as Microcontroller-Out-Sensor-In (MOSI) pin for the SPI communication with the IMU, handlebar motor encoder, and fork motor encoder.
- Pin 12 – Used as Microcontroller-In-Sensor-Out (MISO) pin for the SPI communication with the IMU, handlebar motor encoder, and fork motor encoder.
- Pin 13 – Used as Serial Clock (SCK) pin for the SPI communication with the IMU, handlebar motor encoder, and fork motor controller.
- Pin 20 – Used to read the signal from the Force Transducer. Needs to be Analog.
- Pin 21 – Used to read the signal from the Torque sensor. Needs to be Analog.
- Pins 22 and 23 – Used for the pedal encoder. Both pins need to be Digital with Interrupt capabilities (all digital pins on Teensy 3.6).

- Pin 24 – Used as a CS pin for the SPI communication with the handlebar motor encoder.
- Pin 25 – Used as a CS pin for the SPI communication with the fork motor encoder.
- Pin 26 – Used to send power to the handlebar and fork encoders. Needs to be Digital.
- Pin 27 – Used to control the LED on the handlebars. Needs to be Digital.
- Pin 28 – The switch located on the handlebars is connected to this pin. Needs to be Digital.
- Pin 29 – Used to turn on or off the handlebar motor. Needs to be Digital.
- Pin 30 – Used to turn on or off the fork motor. Needs to be Digital.
- Pin 33 – Used to read the torque of the fork motor. Needs to be Analog.
- Pin 34 – Used to read the torque of the handlebar motor. Needs to be Analog.

1.1.3 Teensy 4.1

Teensy 3.6 has been discontinued (as of April 2022) and is out of stock. Therefore, in order to ensure the longevity of the bicycle, it was decided to move to Teensy 4.1, as it is going to be significantly easier to obtain spare microcontrollers in the event of Teensy getting damaged.

The pinout of the Teensy changed slightly between the versions 3.6 and 4.1. The most impactful change was the location of the Analog pins. For this exact application, this meant that pins 33 and 34 are no longer Analog and the wires need to be redirected to other pins. Pins 40 and 41 were chosen as replacements, respectively.

Starting from here, the documentation assumes that Teensy 4.1 is used.

1.2 Microcontroller Board

This is a custom made PCB that was designed by Oliver Lee, Georgios Dialynas, and Andrew Berry. This PCB is used in both the Steer-by-Wire bicycle and the fixed-base Bicycle Simulator. It is designed as an expansion board for the STM32-H405, that features an MPU-9250 IMU, two Ethernet ports, an SD card reader and was designed to be used together with the Power supply board discussed later.

However, now a Teensy is used instead of the STM32-H405, therefore, most of the Teensy's pins are connected to this board to the EXT1 and EXT2 headers, where the STM32-H405 would sit.

The PCB schematic can be found in either [GitHub/oliverlee/gyropcb](https://github.com/oliverlee/gyropcb) or its fork [GitHub/gdialynas/gyropcb](https://github.com/gdialynas/gyropcb) under the name `mc_pcb`.

1.2.1 Board's Pinout

This board features two 26-pin headers EXT1 and EXT2 in the middle of the board. These headers were made for the [OLIMEX STM32-H405](https://www.olimex.com/dev/boards/olimex-stm32-h405.html) microcontroller. There are also seven 2-pin headers (from J10 to J16), three 4-pin headers (J3, J4, J5), two 6-pin headers (J8, J9), and two 8-pin headers (J6, J7) along the sides of the board. For the Steer-by-Wire application, four more wires are soldered to the pads

on the PCB in the location, where a U4 IC chip should be soldered. These are the functions of each header:

EXT1 (Pin numbering according to the [OLIMEX User Guide, page 9](#)):

- Pin 2 (PA8) – Connected to Pin 8 of the Teensy.
- Pin 4 (PA9) – Connected to Pin 9 of the Teensy.
- Pin 5 (3.3V VDD) – Connected to 3.3V (between Pins 12 and 24) on Teensy.
- Pin 6 (GND) – Connected to GND (above Pin 23) on Teensy.
- Pin 7 (PA10) – Connected to Pin 26 of the Teensy.
- Pin 14 (PA6) – Connected to Pin 12 of the Teensy.
- Pin 18 (PA5) – Connected to Pin 13 of the Teensy.
- Pin 19 (PC0) – Connected to Pin 41 of the Teensy.
- Pin 20 (PC1) – Connected to Pin 40 of the Teensy.
- Pin 21 (PB0) – Connected to Pin 10 of the Teensy.
- Pin 22 (PA7) – Connected to Pin 11 of the Teensy.

EXT2 (Pin numbering according to the [OLIMEX User Guide, page 9](#)):

- Pin 2 (PC2) – Connected to Pin 21 on Teensy.
- Pin 4 (PA0) – Connected to Pin 2 on Teensy.
- Pin 6 (GND) – Connected to GND (above Pin 0) on Teensy.
- Pin 8 (PA1) – Connected to Pin 3 on Teensy.
- Pin 10 (PA3) – Connected to Pin 25 on Teensy.
- Pin 11 (PA4) – Connected to Pin 24 on Teensy.
- Pin 16 (PB13) – Connected to Pin 30 on Teensy.
- Pin 17 (PB12) – Connected to Pin 29 on Teensy.
- Pin 20 (PC6) – Connected to Pin 22 on Teensy.
- Pin 21 (PC7) – Connected to Pin 23 on Teensy.
- Pin 25 (GND_VSS) – Wire is connected to the USB-micro cable to supply power to Teensy. Black wire.
- Pin 26 (VIN) – Wire is connected to the USB-micro cable to supply power to Teensy. Red wire.

2-pin headers:

- J10 – Cable labelled **Analog output, handlebar motor**.
- J11 – Cable labelled **Analog output, fork motor**.
- J12 – Cable labelled **Torque sensor value**.
- J13 – A grey wire is connected to the right pin (assuming that the SD card slot is closer to the observer and ethernet ports are further).
- J14 – A yellow wire leading to a resistor and labelled **Y** is connected to the right pin (assuming that the SD card slot is closer to the observer and ethernet ports are further).
- J15 – A black wire labelled **X** is connected to the right pin (assuming that the SD card slot is closer to the observer and ethernet ports are further).
- J16 – Cable labelled **Torque sensor measure enable**.

4-pin headers:

- J3 – Cable labelled **1**.

- J4 – This header is used to power the Bluetooth module. Red wire goes to +5V, while the brown wire goes to GND.
- J5 – Cable labelled 2.

6-pin headers:

- J8 – Cable labelled 6., with orange and white wires at the top pins (assuming that the SD slot is at the bottom of the board).
- J9 – Cable labelled 8, with orange and white wires at the top pins (assuming that the SD slot is at the bottom of the board).

8-pin headers:

- J6 – Cable labelled 3.
- J7 – Cable labelled 7.

1.3 Power Board

This is a custom made PCB that was designed by Oliver Lee, Georgios Dialynas, and Andrew Berry. This PCB is used in both the Steer-by-Wire bicycle and the fixed-base Bicycle Simulator. It is a power supply board that interfaces with two [Maxon ESCON 50/5](#) servo controller modules.

The PCB schematic can be found in either [GitHub/oliverlee/gyropcb](#) or its fork [GitHub/gdialynas/gyropcb](#) under the name `power_pcb`.

1.3.1 Board's Pinout

In the middle of the board, there are two 18-pin headers EXT1 and EXT3, and two 11-pin headers EXT2 and EXT4. These headers are used to seat the ESCON modules. There are also four 2-pin headers (J10, J11, J12, J16), one 5-pin header (J5), two 6-pin headers (J2, J4), and four 8-pin headers (J1, J3, J6, J7) along the sides of the board. There are also two 4-pin headers glued on the bottom side of the board. These are the functions of each header:

Headers EXT1 and EXT2 are used to seat the handlebar motor's ESCON module.

Headers EXT3 and EXT4 are used to seat the fork motor's ESCON module.

2-pin headers:

- J10 – Cable labelled `Analog output`, handlebar motor.
- J11 – Cable labelled `Analog output`, fork motor.
- J12 – Cable labelled `Torque sensor value`.
- J16 – Cable labelled `Torque sensor measure enable`.

5-pin header J5: wire labelled `Output torque sensor` is connected to the VAL pin, while the red and black cables going to the protoboard are connected to the +18V and GND pins, respectively.

6-pin headers:

- J2 – Cable labelled 9..
- J4 – Cable labelled 13.

8-pin headers:

- J1 – Cable labelled 10.
- J3 – Cable labelled 14.
- J6 – Cable labelled 3.
- J7 – Cable labelled 7.

Glued 4-pin headers:

- The header under the inductor – Cable labelled 11.
- The header not under the inductor – Cable labelled 12.