



Setting default routes for a complex network of routers



Check for ping from PC0 to verify if there are no losses in the network

Vis.	Time(sec)	Last Device	At Device	Type	Info
	278.307	Router1	Router2	CDP	
	286.065	--	Router2	CDP	
	286.065	--	Router2	CDP	
	286.066	Router2	PC1	CDP	
	286.066	Router2	Router1	CDP	
	331.708	--	Router0	CDP	
	331.708	--	Router0	CDP	
	331.709	Router0	PC0	CDP	
	331.709	Router0	Router1	CDP	

Message received by PC1 from PC0