

start



end



$\Delta t$

Sequence  
Controller

topic:  
setpoint/state

Loop controller

topic:  
loop/currentstate

Lenovo, Ubuntu 22.04

Teensy 4.0

