



Use ESP32 Pin A5 to detect if the phone is off hook. When off hook, the voltage around R2 drops to a lower value. A microcontroller can detect this using a threshold.

C1 isolates the AC component from the rest of the circuit, then sends it through a transistor amplifier, then into ESP32 Pin A4 which is filtered by C2.

Schematic	Custom Telephone Exchange		Create at	2025-05-04
			Update at	2025-06-02
Board			Page	P1
Drawn		Vanguard 4001AR		
Reviewed				
		Version	Size	Page 1 Total 1
EasyEDA		V1.0	A4	EasyEDA.com