

## (wafer2,0,7,-1,-1,0,2) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 19
- Last Stimulated = 2022/March/28 at 04:22:30PM

-----  
Stimulated at 04:11:33PM on 2022/March/28

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Formed at 0.3V, weird



## Probe B plots



-----  
Stimulated at 04:12:51PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:13:20PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did Not Set

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:13:56PM on 2022/March/28

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 35.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset\*

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:14:28PM on 2022/March/28

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = formed at 4.7V

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:15:25PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Did not reset



## Probe A plots



## Probe B plots



-----  
Stimulated at 04:15:52PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did Reset

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:16:37PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not set

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:16:53PM on 2022/March/28

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V


Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset\*



## Probe B plots



-----  
Stimulated at 04:17:10PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 4.55V

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:17:34PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset





## Probe B plots



-----  
Stimulated at 04:18:21PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did Reset, high reset voltage -4.45

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:19:01PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = set at 3.6V

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:19:28PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did Reset at good voltage

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:19:56PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.45V

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:20:58PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset successfully

## Probe A plots



## Probe B plots



-----  
 Stimulated at 04:21:40PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V



Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = set at 4.5V

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:22:14PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset successfully

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:22:30PM on 2022/March/28

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = set at 4V

## Probe A plots



## Probe B plots



-----