

(wafer2,0,1,-1,-1,1,0) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 24
- Last Stimulated = 2022/March/17 at 03:58:40PM

Stimulated at 03:13:48PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 20.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Formed at 4.9 V



Probe B plots



Stimulated at 03:14:23PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA



Platinum Voltage = 0V

Copper Voltage = 0.100V



Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set*

Probe A plots



Probe B plots



Stimulated at 03:15:00PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s


Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset





Stimulated at 03:15:52PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset

Probe A plots



Probe B plots



Stimulated at 03:17:30PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did reset



Probe B plots



Stimulated at 03:18:05PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset*

Probe A plots



Probe B plots



Stimulated at 03:18:32PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 1.30 V

Probe A plots



Probe B plots



Stimulated at 03:23:25PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset

Probe A plots



Probe B plots



Stimulated at 03:24:15PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset

Probe A plots



Probe B plots



Stimulated at 03:26:23PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = RR too high

Probe A plots



Probe B plots



Stimulated at 03:27:25PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset





Stimulated at 03:28:11PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



 Stimulated at 03:28:38PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 20.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Not conducting State: Reset*





Stimulated at 03:40:02PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA



Platinum Voltage = 0V

Copper Voltage = 0.100V



Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set*

Probe A plots



Probe B plots



Stimulated at 03:40:42PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s


Compliance Current = 6.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset



Probe B plots



Stimulated at 03:42:45PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = reset

Probe A plots



Probe B plots



Stimulated at 03:43:18PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 20.0uA

Platinum Voltage = 0V


Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Super-reset State: Reset*



Probe B plots



Stimulated at 03:44:04PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 1.30 V

Probe A plots



Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset. Amrita is sad

Probe A plots





Stimulated at 03:55:59PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA



Platinum Voltage = 0V

Copper Voltage = 0.100V



Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set*

Probe A plots



Probe B plots



Stimulated at 03:56:52PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Amrita: I have no idea what that is

Probe A plots



Probe B plots



Stimulated at 03:57:28PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA



Platinum Voltage = 0V

Copper Voltage = 0.100V



Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set*

Probe A plots



Probe B plots



Stimulated at 03:57:57PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset

Probe A plots



Probe B plots



Stimulated at 03:58:40PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset.

Probe A plots



Probe B plots

