

(wafer1,2,0,-1,-1,0,0) Plots and Summary

- Cell Size = 15um
- Number of Times Accessed = 8
- Last Stimulated = 2022/February/28 at 04:07PM

Stimulated at 03:54PM on 2022/February/28

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 10.0uA


Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Forming Success. A: Copper, B: Platinum.

Probe A plots





Stimulated at 03:57PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots



 Stimulated at 03:59PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots



Stimulated at 04:00:19PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 5.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots



Stimulated at 04:00:43PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots



Stimulated at 04:02PM on 2022/February/28

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 10.0mA



Platinum Voltage = 0V

Copper Voltage = 0.1V



Run Folder Name = <2 probe, so invalid>

Comments = Still in set. A: Copper, B: Platinum.

Probe A plots



Probe B plots



Stimulated at 04:04PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 10.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots



Stimulated at 04:07PM on 2022/February/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 10.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Failure to reset. A: Copper, B: Platinum.

Probe A plots



Probe B plots

