

(wafer2,0,1,-1,-1,3,4) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 16
- Last Stimulated = 2022/March/17 at 04:36:43PM

Stimulated at 04:21:42PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Not connected





Stimulated at 04:22:35PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Not connected

Probe A plots



Probe B plots



Stimulated at 04:23:25PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Not connected

Probe A plots





Stimulated at 04:24:58PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Not connected

Probe A plots



Probe B plots



Stimulated at 04:25:25PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 20.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Formed at 2.75 V



Probe B plots



Stimulated at 04:26:16PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = No reset

Probe A plots



Probe B plots



Stimulated at 04:26:51PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 6.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset



Probe B plots



Stimulated at 04:27:49PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.8 V

Probe A plots



Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots





Stimulated at 04:29:52PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.2 V

Probe A plots



Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = No reset

Probe A plots



Probe B plots



Stimulated at 04:31:26PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA



Platinum Voltage = 0V

Copper Voltage = 0.100V



Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set*

Probe A plots



Probe B plots



Stimulated at 04:32:29PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s


Compliance Current = 6.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = No reset



Probe B plots



Stimulated at 04:33:07PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = No reset

Probe A plots



Probe B plots



Stimulated at 04:36:05PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = No reset





Stimulated at 04:36:43PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA



Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = No reset

Probe A plots



Probe B plots

