

(wafer2,0,7,-1,-1,1,2) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 5
- Last Stimulated = 2022/March/28 at 04:27:00PM

Stimulated at 04:25:06PM on 2022/March/28

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Formed really quickly, did not reset later on

Probe A plots



Probe B plots



Stimulated at 04:25:26PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not Reset, bad cell

Probe A plots



Probe B plots



Stimulated at 04:26:05PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset again, bad cell

Probe A plots



Probe B plots



 Stimulated at 04:26:33PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset, bad cell

Probe A plots



Probe B plots



Stimulated at 04:27:00PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 10.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Did not reset, bad cell

Probe A plots



Probe B plots

