

(wafer2,2,0,-1,-1,0,4) Plots and Summary

- Cell Size = 15um
- Number of Times Accessed = 30
- Last Stimulated = 2022/March/17 at 05:31:28PM

Stimulated at 04:52:58PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 20.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Early form at 0.2 V



Probe B plots



Stimulated at 04:54:56PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Already set

Probe A plots



Probe B plots



Stimulated at 04:56:00PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset





Stimulated at 04:56:20PM on 2022/March/17

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset*

Probe A plots



Probe B plots



Stimulated at 04:58:08PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 4.25 V

Probe A plots



Probe B plots



Stimulated at 04:59:14PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



 Stimulated at 05:00:05PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.15 V

Probe A plots



Probe B plots



Stimulated at 05:00:47PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



Stimulated at 05:01:30PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.15 V

Probe A plots



Probe B plots



Stimulated at 05:02:14PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



 Stimulated at 05:02:58PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set lower than forming voltage

Probe A plots



Probe B plots



Stimulated at 05:03:56PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



Stimulated at 05:04:52PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 25.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.9 V

Probe A plots



Probe B plots



Stimulated at 05:05:35PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



 Stimulated at 05:06:50PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 30.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.8 V

Probe A plots



Probe B plots



Stimulated at 05:07:29PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

Probe A plots



Probe B plots



Stimulated at 05:11:44PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.15 V

Probe A plots



Probe B plots



Stimulated at 05:12:42PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset with lower resistance, this one makes sense

Probe A plots



Probe B plots



Stimulated at 05:15:32PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 40.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.15 V

Probe A plots



Probe B plots



Stimulated at 05:16:15PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Has a higher resistance despite being set at 40 uA.. doesn't make sense.

Probe A plots



Probe B plots



Stimulated at 05:17:05PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 40.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.0 V

Probe A plots



Probe B plots



Stimulated at 05:18:43PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Has a higher resistance despite being set at 40 uA.. doesn't make sense.

Probe A plots



Probe B plots



 Stimulated at 05:21:12PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 45.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.5 V

Probe A plots



Probe B plots



Stimulated at 05:21:48PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = This and every other reset starting from 184 has the same resistance. e.g. 176, 178, 180, 182, 184, 185

Probe A plots



Probe B plots



 Stimulated at 05:24:35PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 50.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.2 V

Probe A plots



Probe B plots



 Stimulated at 05:25:23PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Has same resistance: 176, 178, 180, 182, 184, 185, 186

Probe A plots



Probe B plots



Stimulated at 05:26:37PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 55.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.35 V

Probe A plots



Probe B plots



 Stimulated at 05:27:49PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Has same resistance: 176, 178, 180, 182, 184, 185, 186, 187

Probe A plots



Probe B plots



 Stimulated at 05:30:32PM on 2022/March/17

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 60.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.85 V

Probe A plots



Probe B plots



Stimulated at 05:31:28PM on 2022/March/17

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = No longer has same resistance

Probe A plots



Probe B plots

