

(wafer2,0,1,-1,-1,4,4) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 5
- Last Stimulated = 2022/March/17 at 04:45:07PM

Stimulated at 04:40:37PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not conduct

Probe A plots



Probe B plots



Stimulated at 04:41:18PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Instantly set

Probe A plots



Probe B plots



Stimulated at 04:42:36PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Still instantly set

Probe A plots



Probe B plots



Stimulated at 04:44:07PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = No conduction

Probe A plots



Probe B plots



Stimulated at 04:45:07PM on 2022/March/17

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Instantly set

Probe A plots



Probe B plots

