

## (wafer2,2,0,-1,-1,0,0) Plots and Summary

- Cell Size = 15um
- Number of Times Accessed = 8
- Last Stimulated = 2022/March/23 at 04:34:50PM

-----  
Stimulated at 04:27:07PM on 2022/March/23

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 20.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Probe A on copper, B on platinum. Cell was already in set.



## Probe B plots



-----  
Stimulated at 04:28:04PM on 2022/March/23

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = reset success but janky.

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:28:43PM on 2022/March/23

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = set success, 2.3V, very low.

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:31:04PM on 2022/March/23

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = reset fail.

## Probe A plots



## Probe B plots



-----  
 Stimulated at 04:31:58PM on 2022/March/23

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 20.0uA

Platinum Voltage = 0V


Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = shows in set. State: Set\*



## Probe B plots



-----  
Stimulated at 04:33:14PM on 2022/March/23

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = reset fail.



## Probe A plots



## Probe B plots



-----  
Stimulated at 04:34:03PM on 2022/March/23

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = reset success. Janky response in the higher voltages of the plot.

### Probe A plots



### Probe B plots



-----  
Stimulated at 04:34:50PM on 2022/March/23

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 20.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = confirmed in reset. State: Reset\*




## Probe B plots

Voltage and Current against Time



Current against Voltage



-----