

Propagation constant and loss

Lossless transmission line

In many practical applications, conductor loss is low $R \rightarrow 0$, and dielectric leakage is low $G \rightarrow 0$. These two conditions describe a lossless transmission line.

In this case, the transmission line parameters are

- Propagation constant

$$\begin{aligned}\gamma &= \sqrt{(R + j\omega L)(G + j\omega C)} \\ \gamma &= \sqrt{j\omega L j\omega C} \\ \gamma &= j\omega\sqrt{LC} = j\beta\end{aligned}$$

- Transmission line impedance will be defined in the next section, but it is also here for completeness.

$$\begin{aligned}Z_0 &= \sqrt{\frac{R + j\omega L}{G + j\omega C}} \\ Z_0 &= \sqrt{\frac{j\omega L}{j\omega C}} \\ Z_0 &= \sqrt{\frac{L}{C}}\end{aligned}$$

- Wave velocity

$$\begin{aligned}v &= \frac{\omega}{\beta} \\ v &= \frac{\omega}{\omega\sqrt{LC}} \\ v &= \frac{1}{\sqrt{LC}}\end{aligned}$$

Learning outcomes: Explain parts of propagation constant and what they represent. Calculate the phase and attenuation constant for specific transmission lines.

Author(s): Milica Markovic

- Wavelength

$$\begin{aligned}\lambda &= \frac{2\pi}{\beta} \\ \lambda &= \frac{2\pi}{\omega\sqrt{LC}} \\ \lambda &= \frac{2\pi}{\sqrt{\epsilon_0\mu_0\epsilon_r}} \\ \lambda &= \frac{c}{f\sqrt{\epsilon_r}} \\ \lambda &= \frac{\lambda_0}{\sqrt{\epsilon_r}}\end{aligned}$$

Voltage and current on lossless transmission line

On a lossless transmission line, where $\gamma = j\beta$ current and voltage simplify to

$$\begin{aligned}\tilde{V}(z) &= \tilde{V}_0^+ e^{-j\beta z} + \tilde{V}_0^- e^{j\beta z} \\ \tilde{I}(z) &= \tilde{I}_0^+ e^{-j\beta z} + \tilde{I}_0^- e^{j\beta z}\end{aligned}$$

What does it mean when we say a medium is lossy or lossless?

In a lossless medium, electromagnetic energy is not turning into heat; there is no amplitude loss. An electromagnetic wave is heating a lossy material; therefore, the wave's amplitude decreases as $e^{-\alpha x}$.

medium	attenuation constant α [dB/km]
coax	60
waveguide	2
fiber-optic	0.5

In guided wave systems such as transmission lines and waveguides, the attenuation of power with distance follows approximately $e^{-2\alpha x}$. The power radiated by an antenna falls off as $1/r^2$. As the distance between the source and load increases, there is a specific distance at which the cable transmission is lossier than antenna transmission.

Low-Loss Transmission Line

This section is optional.

In some practical applications, losses are small, but not negligible. $R \ll \omega L$ and $G \ll \omega C$.

In this case, the transmission line parameters are

- Propagation constant

We can re-write the propagation constant as shown below. In some applications, losses are small, but not negligible. $R \ll \omega L$ and $G \ll \omega C$, then in Equation 2, $RG \ll \omega^2 LC$.

$$\gamma = \sqrt{(R + j\omega L)(G + j\omega C)} \quad (1)$$

$$\gamma = j\omega\sqrt{LC}\sqrt{1 - j\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right) - \frac{RG}{\omega^2 LC}} \quad (2)$$

$$\gamma \approx j\omega\sqrt{LC}\sqrt{1 - j\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right)} \quad (3)$$

Taylor's series for function $\sqrt{1+x} = \sqrt{1 - j\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right)}$ in Equation 3 is shown in Equations 4-5.

$$\sqrt{1+x} = 1 + \frac{x}{2} - \frac{x^2}{8} + \frac{x^3}{16} - \dots \text{ for } |x| < 1 \quad (4)$$

$$\gamma \approx j\omega\sqrt{LC}\sqrt{1 - j\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right)} = j\omega\sqrt{LC}\left(1 - \frac{j}{2}\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right)\right) \quad (5)$$

The real and imaginary part of the propagation constant γ are:

$$\alpha = \frac{\omega\sqrt{LC}}{2}\left(\frac{R}{\omega L} + \frac{G}{\omega C}\right) \quad (6)$$

$$\beta = \omega\sqrt{LC} \quad (7)$$

We see that the phase constant β is the same as in the lossless case, and the attenuation constant α is frequency independent. All frequencies

metal resistance is lower than the inductive impedance
dielectric conductance is lower than the capacitive impedance

of a modulated signal are attenuated the same amount, and there is no dispersion on the line. When the phase constant is a linear function of frequency, $\beta = \text{const} \omega$, then the phase velocity is a constant $v_p = \frac{\omega}{\beta} = \frac{1}{\text{const}}$, and the group velocity is also a constant, and equal to the phase velocity. In this case, all frequencies of the modulated signal propagate at the same speed, and there is no distortion of the signal.

Transmission-line parameters R, G, C, and L

To find the complex propagation constant γ , we need the transmission-line parameters R, G, C, and L. Equations for R, G, C, and L for a coaxial cable are given in the table below.

Transmission-line	R	G	C	L
Coaxial Cable	$\frac{R_{sd}}{2\pi} \left(\frac{1}{a} + \frac{1}{b} \right)$	$\frac{2\pi\sigma}{\ln b/a}$	$\frac{2\pi\epsilon}{\ln b/a}$	$\frac{\mu}{2\pi} \ln b/a$

Where $R_{sd} = \sqrt{\pi f \mu_m / \sigma_m}$ is the resistance associated with skin-depth. f is the frequency of the signal, μ_m is the magnetic permeability of conductors, σ_c is the conductivity of conductors.

Example 1. Calculate capacitance per unit length of a coaxial cable if the inner radius is 0.02 m, the outer radius is 0.06 m, the dielectric constant is $\epsilon_r = 2$. Use the applet below, Matlab, Matematica, or other software that you use.

Geogebra link: <https://tube.geogebra.org/m/whkrg2pu>