


476t...KiB) 796.4 GiB free



13-startup — Dolphin

TO 1FA-18C-476CL-1 — Ok...



9. Engine crank switch – L
10. Left throttle – IDLE (15% RPM minimum)
11. Engine crank switch – Check OFF
12. IFEI – Check

BEFORE TAXI

1. Waypoint zero and magnetic variation – Check
2. Inertial navigation system – ALIGN
 - a. Shore based operations – GND
 - b. CV based operations – CV
3. Radar – OPERATE
4. Wingfold – SPREAD and LOCK
5. FCS reset button – PUSH (If wings are folded, verify aileron Xs are present)
If no reset
 - a. T.O. Trim button – PUSH (note TRIM advisory)
 - b. FCS exerciser mode – INITIATE (Lift FCS BIT consent switch and push FCS reset button simultaneously)**If still no reset**
 - a. FCS circuit breakers – PULL 4 channels
 - b. Wait 10 seconds
 - c. FCS circuit breakers – RESET
 - d. FCS reset button – PUSH
6. Flaps – AUTO
7. FCS reset button and paddle switch – Actuate simultaneously
8. Flaps – HALF
9. FCS initiated BIT – Perform

8 of 28

17:14:53 (UTC)
2020-03-25