


Master-In Slave-out not needed



Magnetometer
or
Blue SM:RF

→ COULD USE WIRE
FOR THIS SO WE
DON'T HAVE TO SOLDER
IT

OR OTHER
WAY AROUND