


- PB0 -
- PB1 - CS_CONN_1
- PB2 - CS_FRAM
- PB3 - CS_CONN_2
- PB4 - CS_SDCARD
- PB5 - MOSI_SPI
- PB6 - MISO_SPI
- PB7 - SCK_SPI

VOLTAGE REFERENCE







Title:

Author:





Size: A4

Page: 3/6

Date:



INERTIAL MEASUREMENT UNIT



Title:

Author:

Size: A4


Page: 4/6

Date:




PIXHAWK STANDARD HEADERS


UART CONN.



I2C CONN.




SPI CONN.




PIN HEADERS


ANALOG CONN



AUX_I2C CONN



I2C CONN



Title:

Author:

Size: A4


Page: 5/6

Date:




SUPERCAP MANAGEMENT

Supercap charge current = 0 A
if load current = 1 A
 $R_s = 25 \text{ mV} / I_{\text{load}}$



BUCK-BOOST CONVERTOR



Title:


Author:

Size: A4

Page: 6/6

Date:





Title:

Author:

Size: A4

Page: 6/6

Date:

