



## Front



## Back



- $\varnothing 1/2"$  and  $\varnothing 3/8"$  need  $\varnothing 1/8"$  pilots
- Use file and nibbler after test fit
- Trim Service Unit board corners