

LED Font Generator 2.0

User's Manual

<http://www.lcddesigner.com/english>



COPYRIGHT NOTICE

Copyright ©2008 Modern Noorsun Electronics
All rights reserved.

Modern Noorsun Electronics
email: info@lcd designer.com
web: www.lcd designer.com/english

Contents

Introduction.....	1
Main Features.....	2
Installation	3
Software Overview	8
Interface Language Settings.....	9
Program Settings	10
Creating and editing a design.....	11
Design Settings	12
The Character Library	13
Using the Character Library Manually	13
Using the Character Library Automatically	13
Using Special Characters in the Character Library	14
Organizing the Character Library	16
Create Custom Fonts in the Character Library.....	17
How to design a character	17
Using System Fonts	19
Program Output.....	20
The Export Design Window	20
Normal Output	20
Advanced Output	22
Other Output Settings.....	23
Quick Export.....	24
Send Design via Serial Port	25
Import Pictures.....	28
Save Design as Picture.....	29
Convert Code to Design.....	30
Other Tools	31
LED Character Designer.....	32
Design Animator	34
Print a Design.....	35
Keyboard Shortcuts.....	36
General.....	36
Edit.....	36

Introduction

LED Font Generator, The best LCD and LED Font Designer on the market

LED Font Generator is the best and the most complete software for designing LED and LCD font and text. The environment of this software provides powerful features to ease the process of designing dot-matrix fonts and texts.

By using this software, with its professional tools and features, you can design and create interesting fonts and texts easily. The output of this application is completely customizable to meet your programming requirements.

Main Features

1. Multilingual interface
2. Output the design via the serial port
3. Support for English, Farsi, and Arabic font design
4. Convert text to dot-matrix design using all the fonts available on your system
5. Overall preview of the design
6. Zoom in and zoom out
7. Convert text codes to LED and LCD font
8. Undo and redo functions during design
9. Editing functions (Cut, Copy, Paste)
10. Character Library feature for organizing designed fonts
11. Character Library Organizer tool
12. Import pictures (GIF, JPG, BMP, ...) into the design
13. Save design as a picture
14. Fully customizable output (normal and advanced output)
15. Quick export function to speed designing during test stage
16. Full screen view
17. Support for many operations on the design (Rotate, Shift, Toggle, ...)
18. External character designer tool for designing individual characters even more easily
19. Scrolling LED Panel simulator
20. Keyboard shortcuts for more functionality

Installation

This program is not compatible with Windows 98 and older versions of windows. So you cannot install it on this operating system.


To start installing, run the setup program to start the setup wizard.



Press Next to go to the License Agreement page. You must accept this license to continue installing the software on your computer.




In the next window, enter your user information. This information is optional.



The screenshot shows the 'Customer Information' window of the LED Font Generator - InstallShield Wizard. The window has a blue title bar with the application name and a close button. Below the title bar, there's a header area with a document icon and the text 'Customer Information'. The main area is light beige and contains the instruction 'Please enter your information.' followed by two text input fields. The first field is labeled 'User Name:' and contains the text 'LCD Designer Developers'. The second field is labeled 'Organization:' and contains the text 'Modern Noorsun Electronics Corp.'. Below these fields, there's a section titled 'Install this application for:' with two radio button options: 'Anyone who uses this computer (all users)' (which is selected) and 'Only for me (LCD Designer Developers)'. At the bottom of the window, there's a status bar with the 'InstallShield' logo and three buttons: '< Back', 'Next >', and 'Cancel'.


Press Next. In the new window you can select where to install the application. To select another folder, press Change button and select your destination folder.




The screenshot shows the 'Destination Folder' window of the LED Font Generator - InstallShield Wizard. The window has a blue title bar with the application name and a close button. Below the title bar, there's a header area with a document icon and the text 'Destination Folder'. The main area is light beige and contains the instruction 'Click Next to install to this folder, or click Change to install to a different folder.' followed by a folder icon and the text 'Install LED Font Generator to: C:\Program Files\LED Font Generator 2.0\'. To the right of this text is a 'Change...' button. At the bottom of the window, there's a status bar with the 'InstallShield' logo and three buttons: '< Back', 'Next >', and 'Cancel'.

Click Next to continue. In the Setup Type window, you can choose how you want the program to be installed on your computer. In Typical type, all the program features will be installed. If you want to



select which parts to install, select Custom setup type. Then press Next button to proceed to the next step.




If you would choose Custom setup type in the previous stage, in the new window, you can select which program features to install. After customizing your installation, press Next to continue.




In the new stage, a summary of the setup settings is shown. If these information is correct, click Install to start installation process.




After the installation is complete, click the Finish button to finish the setup.



After installing the software, you can run it directly from the desktop,




Or go to the Start menu, into Programs group, the LED Font Generator 2.0 submenu and run the installed application.




Software Overview

The following picture shows the main environment of the LED Font Generator 2.0 when English is selected as the interface language.




Interface Language Settings

LED Font Generator is a multilingual program. By default, there are two languages contained in the setup package. You can choose the interface language of this program from these two languages: Farsi and English. To change the language, go to the Tools menu and select the Language command. The Language form will be shown. Select your desired language and press OK to apply.



Program Settings


To change the program settings, from the Tools menu select Options. The Options window will appear.



In the Character Library section, you can change the path of the Character Library where your fonts and characters are stored. As default, this value is set to the Character Library folder in the installation folder.

The Default Design Size values define the size of the new designs. You can start a new design by choosing the New Design command from the File menu.

As default, when you create a new design, the New Design dialog box appears and allows you to set the size of the new design.



You can prevent this dialog from showing by selecting the "Do not show the New Design dialog box" in the program options window.

To change the number of files stored in the Recently Used File List, which lists the recently used files in the File menu, change the value of "Recently used file list: # entries" in the Options form of the program. A value of 0 disables the Recently Used File List.

One of the important features of the LED Font Generator is the Undo/Redo feature which allows you to undo changes made to a design file during the design process. You can set the number of undo levels in the program Options form.

The "Reset all program settings to default" button resets all of the program settings to their default values.

Creating and editing a design

In the LED Font Generator, each LCD text is saved as a separate design file with extension ".LCD". This allows you to work on your designs continuously.


To start a new design, select New Design from the File menu or press Ctrl+N on your keyboard.

On a design, a cell is called ON when it is filled and is called OFF when it is empty. To change the state of a cell on the design, just click on it. After click, if you hold the mouse button down and move the mouse on the design, the state of all the cells under the mouse pointer will be set to ON. If you hold the Shift key while moving the mouse, all the cells under the mouse pointer will be set to OFF. When you want to do an operation on a group of cells, first you should select the cells. To select a group of cells, use Shift and arrow keys on the keyboard. To change the cursor location on the design, right click on the new cell.


The main commands for editing the design are located under the Design menu. Also for quick access to these commands, there are shortcuts to them on the Design toolbar.

Design Settings

To change the design page settings, select Properties from the Design menu. The shortcut to this command is F4. Also you can double-click on an empty area on the design to show the Design Properties dialog box.



In the Size section, you can change the size of the current design. Also it is possible to change the size of the design directly from the design appearance settings section on top of the design page:



In the Display Options section, you can change the colors of the design page.


The "Use solid colors" option is used to have solid colors on the design. When this option is not selected, the filled cells of the design page have a gradient effect to have a better appearance. The following picture illustrates the difference between these two modes:



The "Advance cursor automatically when inserting..." option controls how the characters are placed on the design from the Character Library. This option will be explained further in this manual.

The Character Library


The Character Library stores a set of predefined characters to be used for writing LED and LCD texts. Using this powerful feature, you can define and create your personal custom fonts. Also it is possible to share your fonts with other designers.



Using the Character Library Manually

You can use the Character Library in two modes: Manual and Automatic. In manual mode, you should pick up individual characters from the Character Library and put them on the design. To do this, first navigate through the character groups on the left side of the Character Library section as shown in the picture above. After finding your desired character, press the Insert button to place it on the design in the current cursor location. Also it is possible to drag and drop characters onto the design using the mouse.


If you want to automatically change the cursor location on the design when inserting new characters, select the following option in the Design Properties dialog box:




Using the Character Library Automatically

Although you can place individual characters on the design, it is possible to let LED Font Generator to automatically choose appropriate characters from the Character Library and put them onto the design.

To use this feature, select the Character Library as the character source in the Text to LCD section. (To show the Text to LCD section, select Text to LCD command from the View menu.)



We illustrate this feature through an example. First, enter your text in the Text field. Then you should define which character groups to be used when converting your text into design. In other words, each of these character groups are a font that you have already created them and put them in the Character Library. By selecting these fonts, you define which font to be used for writing your text.




After selecting your desired fonts, press the Insert As Design button to convert your text using the selected fonts and put it onto the design. The Insert As Design button clears previous contents of the design and replaces with the new text. If you want to place the converted text in a specific location on the design, first put the cursor on that cell and press the Insert At Cursor button to place the converted text in the current cursor location on the design.

The "Adjust design width" and "Adjust design height" options define whether the width and/or height of the design should be adjusted to fit the resulting converted text.

Using Special Characters in the Character Library


There are some special characters that we cannot save them with the name of the corresponding character in the Character Library. Some of these characters which are frequently used are: Space character, ? (Question mark), / (Slash), \ (Backslash), and : (Colon). You should define special names for these characters so that this name will be used to access the character in the Character Library on the disk.

To define or change these names, click the Settings button in the Text to LCD section. This will show up the "Map Characters To Character Names" window. As you see in the following picture, some of the frequently used characters are defined by default. You can change or remove them in this list.




After settings these names, you should save the characters with these names so that they can be used in the Character Library. For example, when you want to create a custom character pattern for the colon (:) character, you should save it with the name COLON.

It is not necessary to remember these names. When saving a character, there is an option that lists all user-defined names:



Organizing the Character Library


The Character Library Organizer tool is used to manage and organize characters into character groups. The Character Library Organizer window is shown in the picture below:



When you select a character group in the left panel, all the characters in that group are shown in a list. You can view, copy and move characters to other character groups easily. Also you can create new character groups (or fonts) in this window.

Using the Rename buttons you can rename a character group or an individual character. To delete a character, select it and then press the Delete button in the middle panel. To delete a character group, select it and press the Delete button in the left panel. Please note that to delete a character group, it should be empty.

To move or copy characters from a character group to another character group, you can use the Copy To and Move To buttons. Another easier way to do this is to use mouse. You can drag and drop characters into the character groups. If you drag characters with the left mouse button, the character will be moved to the new character group. If you do this using the right mouse button, a menu with three options will appear which allow you to copy, move, or cancel the operation:




Create Custom Fonts in the Character Library

To create a new custom font in the Character Library, do the following steps:

1. Create a new character group in the Character Library for your new font (by using the Character Library Organizer tool). The characters you design for your new font will be stored in this new character group. You can create subgroups for this new font for easier management of its characters in the future.
2. Design each of the characters and store them in the Character Library in the newly created font. In the next section we explain how you can create characters.
3. After designing all the characters, your font is ready to be used.


How to design a character

If you use main window of the LED Font Generator to design your characters, select the area on the design page which contains your character. Then go to the Design menu and select the "Create Character from Selection" command or simply press Ctrl+H. This will show the Save Character window as shown in the picture below:



In this window, after selecting the destination folder and defining a name for the character, press the Save button to store the character in the character Library. To access to special character names or user-define character names, press the Special Names button.


Another way to design your characters is to use the Character Designer tool. This tool has a simple interface and allows you to create your characters easily. This tool is explained in the Character Designer Tool section in this manual. The following picture shows the Character Designer tool. To access this tool, choose the Character Designer command from the Tools menu.



Using System Fonts


In addition to the fonts you design, you can use the fonts installed on your system to convert your texts into LED and LCD texts.

To use this feature, go to the Text to LCD section and enter your text. (To show the Text to LCD section, select Text to LCD command from the View menu.) Then, select System Fonts as the character source for your text.



Then, you should select a font to be used when converting your text. The Favorite Fonts tab lists your favorite fonts. You can add any font to this list. To remove a font from the favorite fonts list, select that font and press the "Remove from favorite fonts" button.

In the All Fonts tab, all the fonts installed on your system are listed.



To add a font to the favorite fonts list, press the "Add to favorite fonts" button. As you can see, when you change the selected font, the program automatically calculates the size of the converted text. This helps you to select a font which is suitable for you.

To convert your text using the selected font, press the Insert As Design button. Pressing this button clears previous contents of the design page and puts converted text on the design. To put the converted text in a specific cell on the design, first move the cursor to that cell and press the Insert At Cursor button.


The two options in this section allow you to control how the text is put on the design. These options are described earlier in this manual.

Program Output

The LED Font Generator allows you to completely customize the output code to meet exactly your programming requirements.

The Export Design Window

The Export Design window contains all the options for customizing the output code. The Basic Output tab contains basic output settings. The Advanced Output tab allows you to have more control on the output format. The Other Settings tab contains other miscellaneous options.




To save the output in a file, press the Save button. Also you can copy the output to windows clipboard by pressing the Copy button.

To send the data to serial port, press the Send Through Serial Port button. This feature is more described later in this manual. The Quick Export is also explained in the following sections.

Normal Output

The following picture illustrates all the options in the Basic Output tab:



Advanced Output

If this options is selected, after every n bytes/nibbles/bits (which n is the number specified here), the text entered in the "Separated text" area will be added to the

To break lines into short lines, select this option.

Basic Output ☒ Advanced Output ☒ Other Settings

Column Separators

☒ Add a column separator after every 1 byte(s)

Separator text: ,

☒ Break to new row every 2 byte(s)

Row Separators


☒ Add a row separator after every 1 row(s)

Separator text: ;-----


If selected, after every n lines (which n is the number specified here), the text in the "Separator text" area will be added to the output.

Other Output Settings


The Other Settings tab contains miscellaneous options to control the program output.



When you select the "Mirror bits" option, the program will mirror bits of every data output. For example consider the following design:




By selecting the "Mirror bits" option, the output code will be as shown in the picture below. For instance, in normal mode the last column of the design will be converted to 36 (=00110110), but when the bits are mirrored, it will be 6C (=01101100). The following picture illustrates this mode:



Also, the "Merge rows" option makes it possible to merge short lines of code into long lines. This allows you to have fewer lines of code in the output. The picture above, demonstrates this feature, too.

Quick Export


The Quick Export feature allows you to quickly save the program output in the specified destination when you press F8 key. This helps you to save time when you are in design and test stage. For example, you can set this output to an include file contained in your project. After that, just press F8 to refresh your code and compile and test it again, without any need to manipulate your code manually. The following picture illustrates Quick Export options.



Send Design via Serial Port


It is possible to send the program output to external devices via serial port of your computer. The external device can be a microcontroller or any other device that have serial communication capabilities.

Before you use this feature, you should set the serial communication settings. To do this, go to the Tools menu and select the Serial Communication Settings command. This will show the following window:




In the Port Settings tab you can set the serial port settings (speed, data size, ...) to be compatible with the external device settings.

The Data Settings tab allows you to have more stable communication with your device. In this tab, you can define some initialization bytes (in hex format) that will be sent to the external device before sending the original data. Also, it is possible to define some finalization bytes that will be sent to the serial port after the original data has been sent. The following picture shows the Data Settings tab:



Press OK to apply your settings.


Now whenever you want to send your design data via serial port go to the Export Design window (from File menu, Export Design command) and press the Send Through Serial Port button. The data will be output to the serial port based on the settings you have defined.




This buttons sends the data to serial port based on the specified settings in the Serial Communication Settings window.

Use this button for quick access to the Serial Communication Settings window.

The Customization tab in the Serial Communication Settings window allows you to change the caption of the Send Through Serial Port button in the Export Design window. For example to change the button caption to "Send Data", we can do as the following picture shows:



After confirming this dialog, if you go to the Export Design window, you will notice that the button caption has been changed to "Send Data":




This option allows you to make the output screen more familiar with your needs.

Import Pictures

The current version of the LED Font Generator supports importing these types of graphic files: BMP, JPG, GIF, TIF, and PCX.

To import a picture go to the Import Picture window from File menu, Import Picture command. Select your picture file, set some options and press the Insert As Design or Insert At Cursor button to put it onto the design. The following picture shows the Import Picture window.



This window provides some options to prepare the image before import. You can scale the image to any size, set the foreground color, and select to import only a region on the picture.


Save Design as Picture

To save the current design as a bitmap file, open the Design Picture Preview window. This window displays an overall preview of the current design. Then, right click on any area on this window and choose the Save As Picture command from the popup menu. Select target file name and location and press the Save button to save the picture. The following figure illustrates this task:



Convert Code to Design

The Code to LCD window allows you to convert program codes which contain data definitions of a design to a graphical design. To show this window, press the "Code to LCD" button on the "Import and Export" toolbar. (If this toolbar is not shown, go to the View menu, in the Toolbars submenu select the Import & Export command.)



The following picture illustrates different parts of the Code to LCD window:

Pastes clipboard contents into the code area.

Clears the code area.

When selected, the program automatically detects the format of the input code.

If the "Autodetect code format" option is not selected, you can define the code format here. Usually it is not necessary to do this by yourself, but in some cases where the program is unable to detect the code format correctly, you should define it manually.

The characters you enter here will be ignored during code conversion.

A preview of the result is shown in this area.

Size of the result (Height x Width)

Enables column by column mode. For more information about this mode, see the Program Output section in this manual.

Code to LCD

Code

```
0x000;
0x3b8;
0x208;
0x208;
0x208;
0x208;
0x3b8;
0x000;
```

Settings

☒ Autodetect code format

☐ Bin ☒ Hex

Prefix: Data &B

Suffix:

Ignore these characters: &h*,.,;_-

Preview

☐ Column by column order

Zoom: 100%

☒ Gridlines

8 x 12

Insert As Design


Copy

Other Tools


The LED Font Generator includes several tools that help you create and test you designs.

LED Character Designer

The Character Designer tool provides a simple and easy to use environment for designing LED/LCD characters. This tool completely supports all the editing features of the main program. To start this tool, go to the Tools menu and select the Character Designer command. Also you can run this tool directly from the program group in the windows start menu:




The following picture illustrates different parts of this tool.




To start a new character, just click the Clear Design button. This will clear the design page and make it ready to design a new character.

To save the current character, click the Save Character button. This will show the Save Character dialog box which has been explained in the previous sections of this manual.




To edit a previously designed character, you should first open it in this tool. To open a character, press the Open Character button. This will show the Open Character dialog box:




In this dialog, you can navigate through your Character Library to select a character. After selecting a character, press the Open button to open it. If your character file is not located in the Character Library, you can select the "Other places" option and go to the folder which contains your character file.

Design Animator

The Design Animator tool is used to animate the current working design like in LED scrolling displays. It provides several options to control the scrolling. The following picture illustrates different parts of this tool:




To view the advanced options click the Advanced button:



If the "Output each frame to file" option is selected, each animation frame will be saved to the file specified here. Each time a new frame is saved, previous contents of this file is cleared. But you can use the "Run external program after..." option so that the program will wait until the external program is finished and then generates the next animation frame. The external program, for example, can be a program that sends the animation data stored in the file to a communication port.

Print a Design

To print your design, go to the File menu and select the Print command. This will show the Print Setup command. After selecting the printer, click OK to start printing your design.

In addition to that, there is a print button on the General toolbar () for quick access to this command.

Keyboard Shortcuts

General

Description	Keyboard Shortcut
Create a new design	Ctrl+N
Open a design file	Ctrl+O
Save changes to the current design	Ctrl+S
Show the "Export Design" window	Shift+F8
Quick Export	F8
Import picture	Ctrl+I
Print the design	Ctrl+P
Show/hide the Character Library	Ctrl+Q
Full screen mode	F11
Refresh Character Library	F5
Design properties	F4
Character Library organizer	Ctrl+Shift+G
The Design Animator tool	Ctrl+Shift+N
Program options	Ctrl+J
Displays help in the default help language	F1

Edit

The keyboard shortcuts listed in the table below, are also supported in the Character Designer tool.

Description	Keyboard Shortcut
Undo the last change made to the current design	Ctrl+Z
Redo the previously undid change	Ctrl+Shift+Z
Cut the selected area and copy it onto the clipboard	Ctrl+X
Copy the selected area onto the clipboard	Ctrl+C
Paste cells from the clipboard into the design in the current cursor location	Ctrl+V
Clear selected cells on the design	Del
Select all cells on the design	Ctrl+A
Clear all the cells of the design	Ctrl+Shift+A
Toggles state of the selected cells	Ctrl+Space
Rotate selected cells left	Ctrl+L
Rotate selected cells right	Ctrl+R
Rotate selected cells up	Ctrl+U
Rotate selected cells down	Ctrl+D
Shift cells left	Ctrl+Shift+L
Shift cells right	Ctrl+Shift+R

Description	Keyboard Shortcut
Flip selected cells horizontally	Ctrl+Shift+H
Flip selected cells vertically	Ctrl+Shift+V