


Item	Description	Qty
1	Motor	1
2	Motor Mount Spacer Plate	1
3	Motor Mount	1



Note: Motor is purchased and to be attached to the motor mount with 4xM4 screws. Do not screw more than 6mm into the motor itself or it will be damaged. The motor mount is then attached to spacer plate with 2xM6 screws, at a distance which tensions the timing belt between the motor and wheel axles.

Motor Mount Assembly

Page No.
4

Ryan Husband, u7060611