








US AMATEUR POWER LIMITS — FCC 97.313 An amateur station must use the minimum transmitter power necessary to carry out the desired communications. (b) No station may transmit with a transmitter power exceeding 1.5 kW PEP.

US AMATEUR POWER LIMITS — FCC 97.313 An amateur station must use the minimum transmitter power necessary to carry out the desired communications. (b) No station may transmit with a transmitter power exceeding 1.5 kW PEP.



Note:
CW operation is permitted throughout all amateur bands.
MCW is authorized above 50.1 MHz, except for 144.0-144.1 and 219-220 MHz.
Test transmissions are authorized above 51 MHz, except for 219-220 MHz.

-  = RTTY and data
-  = phone and image
-  = CW *only*
-  = SSB phone
-  = USB phone, CW, RTTY, and data.
-  = Fixed digital message forwarding systems *only*

E = Amateur Extra
A = Advanced
G = General
T = Technician
N = Novice

See www.arrl.org/band-plan for detailed band plans.

We're At Your Service

ARRL Headquarters:
860-594-0200 (Fax 860-594-0259)
email: hq@arrl.org

Publication Orders:
www.arnl.org/shop
Toll-Free 1-888-277-5289 (860-594-0355)
email: orders@arnl.org

Membership/Circulation Desk:
www.aarl.org/membership
Toll-Free 1-888-277-5289 (866-594-0338)
email: membership@aarl.org

Getting Started in Amateur Radio:
Toll-Free 1-800-326-3942 (860-594-0355)
email: newham@arrl.org

Exams: 860-594-0300 email: vec@amrl.org

Copyright © ARRL 2023 rev. 07/25/2024

Considerate Frequency Usage

1.800–2.000	CW	14.233	D-SSTV
1.800–1.810	Digital Modes	14.236	Digital Voice
1.810	CW QRP calling frequency	14.285	QRP SSB calling frequency
1.843–2.000	SSB, SSTV and other wideband modes	14.286	AM calling frequency
1.910	SSB QRP	18.100–18.105	RTTY/Data
1.995–2.000	Experimental	18.105–18.110	Automatically controlled data stations
1.999–2.000	Beacons	18.110	IBP/NCDXF beacons
3.500–3.510	CW DX window	18.162.5	Digital Voice
3.560	QRP CW calling frequency	21.060	QRP CW calling frequency
3.570–3.600	RTTY/Data	21.070–21.110	RTTY/Data
3.585–3.600	Automatically controlled data stations	21.090–21.100	Automatically controlled data stations
3.590	RTTY/Data DX	21.150	IBP/NCDXF beacons
3.790–3.800	DX window	21.340	SSTV
3.845	SSTV	21.385	QRP SSB calling frequency
3.885	AM calling frequency	24.920–24.925	RTTY/Data
3.985	QRP SSB calling frequency	24.925–24.930	Automatically controlled data stations
7.030	QRP CW calling frequency	24.930	IBP/NCDXF beacons
7.040	RTTY/Data DX	28.060	QRP CW calling frequency
7.070–7.125	RTTY/Data	28.070–28.120	RTTY/Data
7.100–7.105	Automatically controlled data stations	28.120–28.189	Automatically controlled data stations
7.171	SSTV	28.190–28.225	Beacons
7.173	D-SSTV	28.200	IBP/NCDXF beacons
7.285	QRP SSB calling frequency	28.385	QRP SSB calling frequency
7.290	AM calling frequency	28.680	SSTV
10.130–10.140	RTTY/Data	29.000–29.200	AM
10.140–10.150	Automatically controlled data stations	29.300–29.510	Satellite downlinks
14.060	QRP CW calling frequency	29.520–29.580	Repeater inputs
14.070–14.095	RTTY/Data	29.600	FM simplex
14.095–14.0995	Automatically controlled data stations	29.620–29.680	Repeater outputs
14.100	IBP/NCDXF beacons		
14.1005–14.112	Automatically controlled data stations		
14.230	SSTV		

References

CW Parse Tree

<https://commons.wikimedia.org/wiki/File:Morse-code-tree.svg>

World Maidenhead Grid Map

<https://www.dxengineering.com/techarticles/dxegeneralnews/download-a-free-worldwide-grid-square-map-from-dx-engineering>

ARRL Frequency Allocation Chart

<https://www.arrl.org/graphical-frequency-allocations>

ARRL Considerate Operator's Frequency Guide

<https://www.arrl.org/considerate-operator>

ARRL Communicating with Other Hams

<https://www.arrl.org/files/file/Get%20on%20the%20Air/Comm%20w%20Other%20Hams-Q%20Signals.pdf>


Icom US Grid Square Map

https://www.icomamerica.com/lineup/amateur/Band_Plan_Map/

Icom Common Prefixes of Countries

<https://www.hamqsl.com/bandchar.pdf>

AR BR CR DR ER FR GR HR IR JK KR LR MR NR OR PR QR RR



Q Codes

QRG	Your exact frequency (or that of ___) is ___ kHz.	Will you tell me my exact frequency (or that of ___)?
QRL	I am busy (or busy with ___).	Are you busy? (Used to ask if frequency is in use)
QRM	Your transmission is being interfered with ___ (1-5).	Is my transmission being interfered with?
QRN	I am troubled by static ___ (1-5).	Are you troubled by static?
QRO	Increase power.	Shall I increase power?
QRP	Decrease power.	Shall I decrease power?
QRQ	Send faster (___ wpm).	Shall I send faster?
QRS	Send more slowly (___ wpm).	Shall I send more slowly?
QRT	Stop sending.	Shall I stop sending?
QRU	I have nothing for you.	Have you anything for me?
QRV	I am ready.	Are you ready?
QRX	I will call you again at ___ (on ___ kHz).	When will you call me again?
QRZ	You are being called by ___ (on ___ kHz).	Who is calling me?
QSB	Your signals are fading.	Are my signals fading?
QSK	I can hear you between signals.	Can I break in on your transmission?
QSL	I am acknowledging receipt.	Can you acknowledge receipt?
QSO	I can communicate with ___ direct (or via ___).	Can you communicate with ___ direct or by relay?
QSP	I will relay to ___.	Will you relay to ___?
QST	General call to all amateurs (CQ ARRL).	-
QSX	I am listening to ___ on ___ kHz.	Will you listen to ___ on ___ kHz?
QSY	Change to another frequency (or ___ kHz).	Shall I change to another frequency?
QTC	I have ___ messages for you (or for ___).	How many messages have you to send?
QTH	My location is ___.	What is your location?
QTR	The time is ___.	What is the correct time?

Prosigns

AR	End of message	Often sent as “di-dah-di-dah-dit” (•-•-•-•)
AS	Stand by	“di-dah-di-di-dit”; used to ask someone to wait
BK	Break	Used to invite the other station to transmit immediately
BT	Separator	Break between thoughts or paragraphs (“dah-di-di-di-dah”)
CL	Closing down	Used when signing off the air permanently or for the day
CQ	Calling any station	General call: “di-dah-di-dah” then “dah-dah-di-dah”
CT	Start of message	Used to begin formal traffic messages
EE	Error	Correcting a mistake; usually sent as “di-di-di-di” rapidly
K	Go ahead	Invitation for the other station to transmit
KN	Go ahead, named station only	Stronger version of K—only the called station should respond
R	Roger (message received)	Confirms receipt of last transmission
SK	End of contact	“Silent Key”; final sign-off (di-di-di-dah-di-dah)
SN	Understood	Used in formal message handling (equivalent to “QSL” or “Roger”)

CN700	CN699	CN698	CN697	CN696	CN695	CN694	CN693	CN692	CN691	CN690	CN689	CN688	CN687	CN686	CN685	CN684	CN683	CN682	CN681	CN680	CN679	CN678	CN677	CN676	CN675	CN674	CN673	CN672	CN671	CN670
DN700	DN699	DN698	DN697	DN696	DN695	DN694	DN693	DN692	DN691	DN690	DN689	DN688	DN687	DN686	DN685	DN684	DN683	DN682	DN681	DN680	DN679	DN678	DN677	DN676	DN675	DN674	DN673	DN672	DN671	DN670
EN700	EN699	EN698	EN697	EN696	EN695	EN694	EN693	EN692	EN691	EN690	EN689	EN688	EN687	EN686	EN685	EN684	EN683	EN682	EN681	EN680	EN679	EN678	EN677	EN676	EN675	EN674	EN673	EN672	EN671	EN670
FN700	FN699	FN698	FN697	FN696	FN695	FN694	FN693	FN692	FN691	FN690	FN689	FN688	FN687	FN686	FN685	FN684	FN683	FN682	FN681	FN680	FN679	FN678	FN677	FN676	FN675	FN674	FN673	FN672	FN671	FN670
GN700	GN699	GN698	GN697	GN696	GN695	GN694	GN693	GN692	GN691	GN690	GN689	GN688	GN687	GN686	GN685	GN684	GN683	GN682	GN681	GN680	GN679	GN678	GN677	GN676	GN675	GN674	GN673	GN672	GN671	GN670
HN700	HN699	HN698	HN697	HN696	HN695	HN694	HN693	HN692	HN691	HN690	HN689	HN688	HN687	HN686	HN685	HN684	HN683	HN682	HN681	HN680	HN679	HN678	HN677	HN676	HN675	HN674	HN673	HN672	HN671	HN670
IN700	IN699	IN698	IN697	IN696	IN695	IN694	IN693	IN692	IN691	IN690	IN689	IN688	IN687	IN686	IN685	IN684	IN683	IN682	IN681	IN680	IN679	IN678	IN677	IN676	IN675	IN674	IN673	IN672	IN671	IN670
KN700	KN699	KN698	KN697	KN696	KN695	KN694	KN693	KN692	KN691	KN690	KN689	KN688	KN687	KN686	KN685	KN684	KN683	KN682	KN681	KN680	KN679	KN678	KN677	KN676	KN675	KN674	KN673	KN672	KN671	KN670
LN700	LN699	LN698	LN697	LN696	LN695	LN694	LN693	LN692	LN691	LN690	LN689	LN688	LN687	LN686	LN685	LN684	LN683	LN682	LN681	LN680	LN679	LN678	LN677	LN676	LN675	LN674	LN673	LN672	LN671	LN670
ON700	ON699	ON698	ON697	ON696	ON695	ON694	ON693	ON692	ON691	ON690	ON689	ON688	ON687	ON686	ON685	ON684	ON683	ON682	ON681	ON680	ON679	ON678	ON677	ON676	ON675	ON674	ON673	ON672	ON671	ON670
PN700	PN699	PN698	PN697	PN696	PN695	PN694	PN693	PN692	PN691	PN690	PN689	PN688	PN687	PN686	PN685	PN684	PN683	PN682	PN681	PN680	PN679	PN678	PN677	PN676	PN675	PN674	PN673	PN672	PN671	PN670
QN700	QN699	QN698	QN697	QN696	QN695	QN694	QN693	QN692	QN691	QN690	QN689	QN688	QN687	QN686	QN685	QN684	QN683	QN682	QN681	QN680	QN679	QN678	QN677	QN676	QN675	QN674	QN673	QN672	QN671	QN670
RN700	RN699	RN698	RN697	RN696	RN695	RN694	RN693	RN692	RN691	RN690	RN689	RN688	RN687	RN686	RN685	RN684	RN683	RN682	RN681	RN680	RN679	RN678	RN677	RN676	RN675	RN674	RN673	RN672	RN671	RN670
SN700	SN699	SN698	SN697	SN696	SN695	SN694	SN693	SN692	SN691	SN690	SN689	SN688	SN687	SN686	SN685	SN684	SN683	SN682	SN681	SN680	SN679	SN678	SN677	SN676	SN675	SN674	SN673	SN672	SN671	SN670
TN700	TN699	TN698	TN697	TN696	TN695	TN694	TN693	TN692	TN691	TN690	TN689	TN688	TN687	TN686	TN685	TN684	TN683	TN682	TN681	TN680	TN679	TN678	TN677	TN676	TN675	TN674	TN673	TN672	TN671	TN670
UN700	UN699	UN698	UN697	UN696	UN695	UN694	UN693	UN692	UN691	UN690	UN689	UN688	UN687	UN686	UN685	UN684	UN683	UN682	UN681	UN680	UN679	UN678	UN677	UN676	UN675	UN674	UN673	UN672	UN671	UN670
VN700	VN699	VN698	VN697	VN696	VN695	VN694	VN693	VN692	VN691	VN690	VN689	VN688	VN687	VN686	VN685	VN684	VN683	VN682	VN681	VN680	VN679	VN678	VN677	VN676	VN675	VN674	VN673	VN672	VN671	VN670
WN700	WN699	WN698	WN697	WN696	WN695	WN694	WN693	WN692	WN691	WN690	WN689	WN688	WN687	WN686	WN685	WN684	WN683	WN682	WN681	WN680	WN679	WN678	WN677	WN676	WN675	WN674	WN673	WN672	WN671	WN670
YN700	YN699	YN698	YN697	YN696	YN695	YN694	YN693	YN692	YN691	YN690	YN689	YN688	YN687	YN686	YN685	YN684	YN683	YN682	YN681	YN680	YN679	YN678	YN677	YN676	YN675	YN674	YN673	YN672	YN671	YN670
ZN700	ZN699	ZN698	ZN697	ZN696	ZN695	ZN694	ZN693	ZN692	ZN691	ZN690	ZN689	ZN688	ZN687	ZN686	ZN685	ZN684	ZN683	ZN682	ZN681	ZN680	ZN679	ZN678	ZN677	ZN676	ZN675	ZN674	ZN673	ZN672	ZN671	ZN670

Callsign Country Prefixes

K, N, W	United States	CT	Portugal
AA–AL	United States	LU	Argentina
VE	Canada	PY	Brazil
VA, VO, VY	Canada	CX	Uruguay
ZL	New Zealand	YV	Venezuela
VK	Australia	XE	Mexico
JA, JE, JH	Japan	TI	Costa Rica
G, M	United Kingdom	OA	Peru
F	France	CE	Chile
DL	Germany	HL	South Korea
I	Italy	BY, BG, BH	China
ON	Belgium	HS	Thailand
PA	Netherlands	9V	Singapore
SM, SA	Sweden	VU	India
OH	Finland	4X, 4Z	Israel
LA, LB	Norway	ZS	South Africa
OE	Austria	SU	Egypt
OK	Czech Republic	A6	United Arab Emirates
SP	Poland	A7	Qatar
HA	Hungary	A9	Bahrain
YU	Serbia	9K	Kuwait
EA	Spain		

A Alpha _ _	N November _ _	0 _ _ _ _ _	‘ _ _ _ _ _
B Bravo _ _ _	O Oscar _ _ _	1 _ _ _ _	! _ _ _ _
C Charlie _ _ _	P Papa _ _ _	2 _ _ _ _	/ _ _ _
D Delta _ _	Q Quebec _ _ _ _	3 _ _ _	(_ _ _ _
E Echo _	R Romeo _ _	4 _ _ _) _ _ _ _
F Foxtrot _ _ _	S Sierra _ _	5 _ _ _	& _ _ _
G Golf _ _ _	T Tango _	6 _ _ _	: _ _ _ _
H Hotel _ _ _	U Umbrella _ _	7 _ _ _	; _ _ _ _
I India _ _	V Victor _ _ _	8 _ _ _ _	= _ _ _
J Juliet _ _ _ _	W Whiskey _ _ _	9 _ _ _ _	+ _ _ _
K Kilo _ _ _	X X-ray _ _ _ _	. _ _ _ _	- _ _ _ _
L Lima _ _ _	Y Yankee _ _ _ _	, _ _ _ _	_ _ _ _ _
M Mike _ _	Z Zulu _ _ _	? _ _ _	

A: “R TNX MIKE. 73 ES HPE CUAGN. W2XYZ DE K1ABC SK”
(Roger, thanks Mike. Best regards and hope to see you again. Signing off.)