


Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
IF1	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
IF2	
IG2	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IG3	
IG4	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH1	
IH2	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH3	
II1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IJ1	Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel)