



Stored in ROM

Loaded from a file
called MLO in a FAT
filesystem in the
first bootable
partition

Runs from SRAM

Loaded from a file
called u-boot.img in a FAT
filesystem

Runs from RAM