

ROM Code

stored in ROM
in the CPU



Header

U-Boot

stored in NAND or SD
runs from DRAM



Linux Kernel

stored in NAND, SD, network
runs from DRAM