


YS2R6X400E9183544 / VIS, Visibility system / E 32, CUV control unit / CUV1 / S, Switches / S140, Extra lighting module



S140, Extra lighting module

---

## **S140, Extra lighting module**

The role of the circuit is to control the front and rear foglights, bumper-mounted spotlights, sun visor-mounted spotlights and the work light.

The circuit consists of five switches: S8 - Rear foglight  
S9 - Front foglight  
S10 - Bumper-mounted spotlights  
S27 - Sun visor-mounted spotlights  
S18/S58 - Work light  
All switches are spring-loaded. When the switch is pressed, the control unit input is grounded and the requested service is activated. Each switch contains a diode which, when activated, comes on and is grounded via the control unit input by a PWM signal.

### **Switch, front foglight**

When the switch is depressed, this function will be active.

### **Switch, rear foglight**

When the switch is depressed, this function will be active.

### **Switch, spotlights in bumper**

This function can be used to activate the control unit output for the spotlights in the bumper.

### **Switch, spotlights in sun visor**

This function can be used to activate the control unit output for the spotlights in the sun visor.

### **Switch, work light**

When the switch is depressed, this function will be active.

---