


YS2R6X400E9183445 / EMS, Engine Management System / E 44, EMS control unit / S6 / V, Solenoid valves / V2, Coupling coil for A/C compressor V2

---



V2, Coupling coil for A/C compressor V2

---

## V2, Coupling coil for A/C compressor V2

The circuit allows the engine control unit to activate the A/C compressor coupling coil.

When activating the clutch coil, the A/C compressor starts to rotate. The A/C compressor clutch coil is controlled by a signal from the engine control unit. Each time the engine is started, the A/C compressor is operated because the clutch coil is activated via the engine control unit. If the coolant temperature is too high, the engine control unit will not activate the A/C compressor clutch coil.

---