


YS2R6X400E5345662 / COO, Coordinator / E 30, COO control unit / COO7 / V, Solenoid valves / V13, Solenoid valve for EG power take-off



V13, Solenoid valve for EG power take-off

V13, Solenoid valve for EG power take-off

The solenoid valve activates the EG power take-off.

The solenoid valve controls the flow of compressed air for the power take-off. When the solenoid valve is supplied with voltage, it opens a compressed air duct and the power take-off is activated. The solenoid valve is closed in the rest position.