


YS2R6X400E5345662 / COO, Coordinator / E 30, COO control unit / COO7 / S, Switches / S4, Supply voltage from starter lock



S4, Supply voltage from starter lock

## S4, Supply voltage from starter lock

The circuit provides information about the starter key position.

The circuit detects that the key is in the starter lock. It also detects whether the key is turned to the drive position.

## **Starter lock, drive position**

Status on coordinator pin A1. Active when circuit closed and 24 V.

## **Starter lock, starter key inserted**

Status on coordinator pin A11. Active when circuit closed and 24 V.

## **Starter lock, start position**

Status on coordinator pin A10. Active when circuit closed and 24 V.

---