


Impedance of RF trace should be controlled by 50 ohm and the length should be kept as short as possible.



TITLE: Wio LTE Cat NB1 v1.02 / GPS

Design:

Date: 08/05/2018 16:12

Sheet: 4/7