



MATERIALS:
 Felt
 Cotton Fabric
 (mid-weight)
 Conductive Tape
 Batting

TOOLS:
 Scissors
 Pencil & Ruler
 Needle & Thread
 FLORA & USB cord
 Alligator Clips


FELT
CUT
x2



FELT
CUT
x2




TIP: Fold in half first and cut to make hole.



TIP: Cut 3.75" square first then corners.

TIP: When cutting printed fabric use "wrong" side to mark .


CONDUCTIVE TAPE
CUT
x1



TIP: You can write on the paper tap side!


**STEP
1**

PEEL OFF PAPER



**STEP
2**



STICKY SIDE
DOWN, PLACE
CENTERED
ON FELT



FOLD UNDER
.5" FROM TIP
TO CREATE A
TAB.

**STEP
3**




DO THE SAME FOR THE OTHER
ONE, AND YOU SHOULD HAVE
TWO!



**STEP
4**

ASSEMBLE SOFT
BUTTON SWITCH
FELT PIECES
SANDWICHING
FELT PIECES WITH
HOLES.
REMEMBER
CONDUCTIVE
TAPE SHOULD BE
FACING INSIDE.


MAKE SURE
TABS ALIGN TO
SHARE A CORNER
LIKE THIS:



TIP: Conductive
tape should
NOT be touching.
Should only be
touching through
holes on felt when
pressed!

**STEP
5**


BASTE FELT LAYERS
SO IT DOESN'T
FALL APART



STEP 6



STOP HERE TO CHECK YOUR
SOFT BUTTON WORKS AND
TO DOWNLOAD THE CODE
ON TO YOUR FLORA.

<http://bit.ly/2pFGHA1>
get your code here!




STEP 7


CAREFULLY SNIP INSIDE CONERS AND BRING TOGETHER THE LENGTH OF THE CORNERS. MAKE SURE THAT THE FABRIC IS FACING INWARD HERE. THE “WRONG” SIDE OF THE FABRIC SHOULD BE VISIBLE WHEN YOU SEW THE EDGES.




FOLD ALONG THIS DIAGONAL LINE

SEW 1/8" FROM EDGE
ALONG
DOTTED LINES






SEW 1/8" FROM EDGE
ALONG
DOTTED LINES




SHOULD LOOK LIKE A BOX
WITH THE BOTTOM OPEN
THE WHEN ALL 4 SEAMS
ARE SEWN.




"WRONG" side
of the fabric.

STEP 8

TURN BOX "RIGHT"
SIDE OUT AND
FOLD IN RAW EDGE
1/8". FINGER
PRESS FOLDED
EDGE.



"RIGHT" side
of the fabric.




INSERT
BATTING
AND THEN
SOFT BUTTON.

STEP 9

PLACE ON SOFT BUTTON
SPACE AND SLIP STITCH TO
SAMPLE

Slip stitch is when
thread is sewn through
sample, through fold of
the button cover then
sew through sample to
underside of hoop.
Repeat!



Keep conductive
tape tab exposed!