

# **Module 3 Assignment**

Nathan Shea Ouedraogo

15th April 2024

## Dimensional Reduction of a Scalar Variable

A dimensional variable  $u$  may be reduced to its non-dimensional form  $\tilde{u}$  by re-centering it to the origin by a scalar  $u_r$  and dividing it by a scalar factor  $u_s$  :

$$\tilde{u} = \frac{u - u_r}{u_s} \quad (1)$$

If we assume that the variable is already centered at the origin,  $u_r$  disappears:

$$\tilde{u} = \frac{u}{u_s} \quad (2)$$

Rearranging to put the equation in terms of the dimensional variable:

$$u_s \tilde{u} = u \quad \square \quad (3)$$

## Dimensional Reduction of a Vector Variable

Given a vector variable  $\vec{u} = \langle u_1, u_2, \dots, u_{n-1} \rangle$ ,  $\vec{u}_n \in \mathbb{R}^n$  with  $n$  number of dimensional elements its non-dimensional form  $\vec{\tilde{u}}$  is:

$$\vec{\tilde{u}} = \left\langle \frac{u_1 - u_{r1}}{u_{s1}}, \frac{u_2 - u_{r2}}{u_{s2}}, \dots, \frac{u_{n-1} - u_{r_{n-1}}}{u_{s_{n-1}}} \right\rangle \quad (4)$$

If we assume the vector is centered at the origin, the equation becomes:

$$\vec{\tilde{u}} = \left\langle \frac{u_1}{u_{s1}}, \frac{u_2}{u_{s2}}, \dots, \frac{u_{n-1}}{u_{s_{n-1}}} \right\rangle \quad (5)$$

If all elements of  $\vec{\tilde{u}}$  have the same dimension, we can scale some by a characteristic factor  $U_0$ :

$$\vec{\tilde{u}} = \left\langle \frac{u_1}{U_0}, \frac{u_2}{U_0}, \dots, \frac{u_{n-1}}{U_0} \right\rangle \quad (6)$$

$$\vec{\tilde{u}} = \frac{1}{U_0} \langle u_1, u_2, \dots, u_{n-1} \rangle \quad (7)$$

And finally we can rearrange the equation in terms of the dimensional vector:

$$U_0 \vec{\tilde{u}} = \langle u_1, u_2, \dots, u_{n-1} \rangle \quad (8)$$

$$U_0 \vec{\tilde{u}} = \vec{u} \quad \square \quad (9)$$

**i) Navier-Stokes Equation for Incompressible Liquids**

$$\rho \left( \frac{\partial \vec{v}}{\partial t} \right) + \left( \vec{v} \cdot \vec{\nabla} \right) \vec{v} = -\vec{\nabla} p + \eta \nabla^2 \vec{v} + \rho \vec{F} \quad (10)$$

**ii) Dimensional Reduction of Time and Pressure**

Applying Equation (1):

$$\tilde{t} = \frac{t - t_r}{t_s} \quad (11)$$

$$\tilde{p} = \frac{p - p_r}{p_s} \quad (12)$$

Applying Equation (2):

$$\tilde{t} = \frac{t}{t_s} \quad (13)$$

$$\tilde{p} = \frac{p}{p_s} \quad (14)$$

Applying Equation (3):

$$t_s \tilde{t} = t \quad (15)$$

$$p_s \tilde{p} = p \quad (16)$$

**iii) Dimensional Reduction of Velocity**

The dimensional velocity vector is:

$$\vec{v} = \begin{bmatrix} v_x \\ v_y \\ v_z \end{bmatrix} \quad (17)$$

Applying equation (4) gives the dimensionless velocity vector:

$$\vec{\tilde{v}} = \begin{bmatrix} \frac{v_x - v_{r_x}}{v_{s_x}} \\ \frac{v_y - v_{r_y}}{v_{s_y}} \\ \frac{v_z - v_{r_z}}{v_{s_z}} \end{bmatrix} \quad (18)$$

Given a characteristic velocity  $V_0$  and using equations (5) & (9):

$$\vec{v} = \frac{1}{V_0} \begin{bmatrix} v_x \\ v_y \\ v_z \end{bmatrix} \quad (19)$$

$$V_0 \vec{v} = \vec{v} \quad \square \quad (20)$$

#### **iv) Dimensional Reduction of the Position Vector**

The position vector is:

$$\vec{f} = \begin{bmatrix} x \\ y \\ z \end{bmatrix} \quad (21)$$

Which by equations (4)-(7) and a characteristic length of  $L_0$  gives the relationship:

$$\vec{f} = L_0 \vec{\tilde{f}} = L_0 \begin{bmatrix} \tilde{x} \\ \tilde{y} \\ \tilde{z} \end{bmatrix} = \begin{bmatrix} L_0 \tilde{x} \\ L_0 \tilde{y} \\ L_0 \tilde{z} \end{bmatrix} = \begin{bmatrix} x \\ y \\ z \end{bmatrix} = \vec{f} \quad \square \quad (22)$$

#### **v) Dimensional Reduction of the Pressure Gradient**

The dimensional pressure gradient is:

$$-\vec{\nabla} p = - \begin{bmatrix} \frac{\partial f(x, y, z)}{\partial x} p_x \\ \frac{\partial f(x, y, z)}{\partial y} p_y \\ \frac{\partial f(x, y, z)}{\partial z} p_z \end{bmatrix} \quad (23)$$

And its dimensionless form:

$$-\vec{\nabla} \tilde{p} = - \begin{bmatrix} \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{x}} \tilde{p}_x \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{y}} \tilde{p}_y \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{z}} \tilde{p}_z \end{bmatrix} \quad (24)$$

Substituting dimensionless quantities from equations (16), (22) into equation (23) gives:

$$-\vec{\nabla}p = - \begin{bmatrix} \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial L_0 \tilde{x}} p_s \tilde{p}_x \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial L_0 \tilde{y}} p_s \tilde{p}_y \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial L_0 \tilde{z}} p_s \tilde{p}_z \end{bmatrix} \quad (25)$$

Since the characteristic length is a constant, it can be pulled out:

$$-\vec{\nabla}p = -\frac{1}{L_0} \begin{bmatrix} \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{x}} p_{s_x} \tilde{p}_x \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{y}} p_{s_y} \tilde{p}_y \\ \frac{\partial \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{z}} p_{s_z} \tilde{p}_z \end{bmatrix} \quad (26)$$

And by equation (24) gives:

$$-\vec{\nabla}p = -\frac{1}{L_0} \vec{\nabla} p_s \tilde{p} \quad \square \quad (27)$$

#### **vi) Dimensional Reduction of the Viscosity Function**

The viscosity function is given by:

$$\eta \nabla^2 \vec{v} = \eta \begin{bmatrix} \frac{\partial^2 f(x, y, z)}{\partial x^2} v_x \\ \frac{\partial^2 f(x, y, z)}{\partial y^2} v_y \\ \frac{\partial^2 f(x, y, z)}{\partial z^2} v_z \end{bmatrix} \quad (28)$$

And when dimensionally reduced:

$$\eta \tilde{\nabla}^2 \vec{v} = \eta \begin{bmatrix} \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{x}^2} \tilde{v}_x \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{y}^2} \tilde{v}_y \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{z}^2} \tilde{v}_z \end{bmatrix} \quad (29)$$

Substituting equation (22) into equation (28) with a characteristic velocity  $V_0$  gives:

$$\eta \nabla^2 \vec{v} = \eta \begin{bmatrix} \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial (L_0 \tilde{x})^2} V_0 \vec{v}_x \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial (L_0 \tilde{y})^2} V_0 \vec{v}_y \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial (L_0 \tilde{z})^2} V_0 \vec{v}_z \end{bmatrix} \quad (30)$$

Pulling out the characteristic length and velocity:

$$\eta \nabla^2 \vec{v} = \frac{\eta V_0}{L_0^2} \begin{bmatrix} \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{x}^2} \vec{v}_x \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{y}^2} \vec{v}_y \\ \frac{\partial^2 \tilde{f}(\tilde{x}, \tilde{y}, \tilde{z})}{\partial \tilde{z}^2} \vec{v}_z \end{bmatrix} \quad (31)$$

And finally, substituting equation (29):

$$\eta \nabla^2 \vec{v} = \frac{\eta V_0}{L_0^2} \tilde{\nabla}^2 \vec{v} \quad \square \quad (32)$$

### **vii) The Reynolds Number (Re)**

The Reynolds number is a scalar value which modulates the dimensionless velocity gradient:

$$Re = \rho \left( \frac{L_0 V_0}{\eta} \right) \quad (33)$$

In the following section we will see how this number is applied.

### viii) Non-Dimensional Navier-Stokes Equation

Substituting equations (15), (16), (20), (27), and (32) into equation (10) gives:

$$\rho \left( \frac{\partial V_0 \vec{v}}{\partial t_s \tilde{t}} + \vec{v} \left( \vec{\nabla} \cdot \vec{v} \right) \right) = -\frac{1}{L_0} \vec{\nabla} p_s \tilde{p} + \frac{\eta V_0}{L_0^2} \tilde{\nabla}^2 \vec{v} + \rho \vec{F} \quad (34)$$

$$\rho \left( \frac{V_0}{t_s} \right) \left( \frac{\partial \vec{v}}{\partial \tilde{t}} \right) + \rho \left( \vec{v} \left( \vec{\nabla} \cdot \vec{v} \right) \right) = -\frac{1}{L_0} \vec{\nabla} p_s \tilde{p} + \frac{\eta V_0}{L_0^2} \tilde{\nabla}^2 \vec{v} + \rho \vec{F} \quad (35)$$

Dividing by the highest order derivative term and assuming negligible contribution from body forces:

$$\left( \frac{L_0^2}{\eta V_0} \right) \rho \left( \frac{V_0}{t_s} \right) \left( \frac{\partial \vec{v}}{\partial \tilde{t}} \right) + \vec{v} \left( \vec{\nabla} \cdot \vec{v} \right) = \left( \frac{L_0^2}{\eta V_0} \right) \left( -\frac{1}{L_0} \vec{\nabla} p_s \tilde{p} \right) + \left( \frac{L_0^2}{\eta V_0} \right) \frac{\eta V_0}{L_0^2} \tilde{\nabla}^2 \vec{v} \quad (36)$$

$$\rho \left( \frac{L_0^2}{\eta} \right) \left( \frac{\partial \vec{v}}{\partial \tilde{t}} \right) + \rho \left( \frac{L_0 V_0}{\eta} \right) \left( \vec{v} \left( \vec{\nabla} \cdot \vec{v} \right) \right) = -\frac{L_0}{\eta V_0} \vec{\nabla} p_s \tilde{p} + \tilde{\nabla}^2 \vec{v} \quad (37)$$

And finally applying equation (33) to equation (37):

$$\rho \left( \frac{L_0^2}{\eta} \right) \left( \frac{\partial \vec{v}}{\partial \tilde{t}} \right) + Re \left[ \vec{v} \left( \vec{\nabla} \cdot \vec{v} \right) \right] = -\frac{L_0}{\eta V_0} \vec{\nabla} p_s \tilde{p} + \tilde{\nabla}^2 \vec{v} \quad (38)$$

## 2

Per equation (33)  $Re$  is defined as:

$$Re = \rho \left( \frac{L_0 V_0}{\eta} \right)$$

Where  $L_0$  and  $V_0$  are characteristic length (hydrodynamic diameter) and characteristic velocity respectively, and  $\rho$  and  $\eta$  are the density and dynamic viscosity of the fluid respectively. If pressure and temperature are assumed to be constant and body forces are assumed to be negligible,  $\rho$  and  $\eta$  can be assumed to be constants.  $Re$  is therefore dependent on two forces; viscosity forces dependent on  $\rho$  and  $\eta$  and inertial forces dependent on  $L_0$  and  $V_0$ .

We can construct two simplified mental models of the physical effect of  $Re$  using our intuition and own experience. We know that viscous fluids like honey have a greater tendency to 'stick' and less tendency to 'flow'. When honey does flow it is slow and smooth with little bubbles or turbulence. However, upon heating honey it becomes much easier to pour which can be modeled as increasing the fluid's velocity. The flow of hot honey is noticeably more chaotic with bubbles and turbulence. Another way to increase this observed chaos would be to increase the diameter of the flowing liquid; honey flowing from the tip of a squeeze bottle is much more smooth than honey flowing from an upturned jar.

In the first model where fluid flow is 'smooth', the system is dominated by viscosity forces ( $Re < 1$ ) and the fluid flow is said to be laminar:

$$\frac{\rho}{\eta} > L_0 V_0 \quad (39)$$

The second model with 'chaotic' flow is dominated by inertial forces ( $Re \gg 1$ ) and the flow is said to be turbulent:

$$\frac{\rho}{\eta} \ll L_0 V_0 \quad (40)$$

Intermediate values are neither fully turbulent nor fully laminar and have contributions by both forces.



### 3

#### Hagen-Poiseuille Flow in a Rectangular Pipe

Given a cross section of a pipe,  $\partial C$ , the flow is said to be under Hagen-Poiseuille conditions if:

1. The system is translation invariant (i.e. exact position is not needed) along a specified axis
2. pressure is unidirectional along the given translationally invariant axis and zero on the other axis
3. no body forces act upon the system
4. For a given cross-section of a pipe,  $C$ , the velocity at any point along the boundary (wall),  $\partial C$ , is zero (no-slip condition)
5. Pressure boundary conditions hold:

$$p(t_i) = p_0 + \Delta p$$

$$p(t_f) = p_0$$

#### i) Navier-Stokes Equation for Incompressible Liquids in Cartesian Coordinates

The convective term of the Navier Stokes equation (eq. 10) is:

$$(\vec{v} \cdot \vec{\nabla}) \vec{v}$$

Since pressure is unidirectional along the z-axis the equation will expand to:

$$(\vec{v} \cdot \vec{\nabla}) \vec{v} = v_x \left( \frac{\partial}{\partial x} v_z \vec{i} \right) + v_y \left( \frac{\partial}{\partial y} v_z \vec{j} \right) + v_z \left( \frac{\partial}{\partial z} v_z \vec{k} \right) \quad (41)$$

Velocity on the xy plane is zero:

$$(\vec{v} \cdot \vec{\nabla}) \vec{v} = (0) \left( \frac{\partial}{\partial x} v_z \vec{i} \right) + (0) \left( \frac{\partial}{\partial y} v_z \vec{j} \right) + v_z \left( \frac{\partial}{\partial z} v_z \vec{k} \right) = v_z \left( \frac{\partial}{\partial z} v_z \vec{k} \right) \quad (42)$$

Since the z-axis is our chosen translationally invariant axis, velocity is zero:

$$(\vec{v} \cdot \vec{\nabla}) \vec{v} = (0) v_z \left( \frac{\partial}{\partial z} v_z \vec{k} \right) = 0 \quad \blacksquare \quad (43)$$

**By equation (43), a system under Hagen-Poiseuille flow have no convection.**

Since convection is zero under Hagen-Poiseuille flow, pressure is the only force which will be acting on our system. Additionally, under Pousseuille flow pressure will be unidirectional along a single axis. Picking the z-axis, we can apply equation (43) to equation (10):

$$0 = -\vec{\nabla}p + \eta \nabla^2 \vec{v} \quad (44)$$

$$\frac{\partial p}{\partial x} + \frac{\partial p}{\partial y} + \frac{\partial p}{\partial z} = \eta \left( \frac{\partial^2 v_z}{\partial x^2} + \frac{\partial^2 v_z}{\partial y^2} + \frac{\partial^2 v_z}{\partial z^2} \right) \quad (45)$$

$$\frac{\partial p}{\partial z} = \eta \left( \frac{\partial^2 v_z}{\partial x^2} + \frac{\partial^2 v_z}{\partial y^2} + \frac{\partial^2 v_z}{\partial z^2} \right) \quad (46)$$

$$\frac{\partial p}{\partial z} = \eta \left( \frac{\partial^2 v_z}{\partial y^2} \right) \blacksquare \quad (47)$$

## ii) Derivation of Fluid Velocity

Given Hagen-Poiseuille flow, the velocity on  $\partial \mathcal{C}$  is zero. Moving away from  $\partial \mathcal{C}$  towards the center of the cross section  $\mathcal{C}$  will increase the velocity with a maxima at the center of  $\mathcal{C}$ . We will define this center point as  $y_0 = 0$ . Physically, this change in velocity is due to sheer stress along the pipe walls increasing drag. Since velocity is symmetrical about  $y_0$  the change in velocity with respect to position will be zero. Therefore  $\frac{\partial v_z}{\partial y} = 0$ . Applying to equation (47) gives a simple second-order ordinary differential equation:

$$\int \eta \frac{\partial^2 v_z}{\partial y^2} dy = \int \frac{\partial p}{\partial z} dy \quad (48)$$

$$\eta \frac{\partial v_z}{\partial y} + C_0 = \frac{\partial p}{\partial z} y \quad (49)$$

$$C_0 = \left( \frac{\partial p}{\partial z} \right) \left( \frac{y_0}{\eta} \right) - \frac{\partial v_{z_0}}{\partial y} \quad (50)$$

$$C_0 = \left( \frac{\partial p}{\partial z} \right) \left( \frac{0}{\eta} \right) - 0 \quad (51)$$

$$C_0 = 0 \quad (52)$$

$$\therefore \frac{\partial p}{\partial z} y = \eta \frac{\partial v_z}{\partial y} \quad \square \quad (53)$$

The no-slip boundary condition states that the velocity on  $\partial \mathcal{C}$  is zero. Let us define the vertical position at the boundary as  $y_1$  and the velocity at the boundary as  $v_{z_1} = 0$ . Applying to equation (53) leaves a first-order ordinary differential equation:

$$\int \eta \frac{\partial v_z}{\partial y} dy = \int \frac{\partial p}{\partial z} y dy \quad (54)$$

$$v_z = \left( \frac{y^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) + C_1 \quad (55)$$

$$C_1 = v_{z_1} - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) \quad (56)$$

$$C_1 = - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) \quad (57)$$

$$v_z = \left( \frac{y^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) \quad (58)$$

$$\therefore v_z = - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) \left( 1 - \frac{y^2}{y_1^2} \right) \blacksquare \quad (59)$$

### iii) Compliance with No-Slip Conditions

If the velocity is non-zero on the boundary of  $\mathcal{C}$ , then the velocity will not be symmetrical. Physically this is due to the fluid experiencing shear stress and drag across the wall which causes non-zero velocity at the wall ('slip') and non-symmetrical velocity. No-slip conditions hold that the velocity at the wall is zero. This is trivial to prove as  $y^2 = y_1^2$  on  $\partial \mathcal{C}$ . Substituting into equation (59) gives:

$$v_z = - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) \left( 1 - \frac{y_1^2}{y_1^2} \right) \quad (60)$$

$$v_z = - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) (1 - 1) \quad (61)$$

$$v_z = - \left( \frac{y_1^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) (0) \quad (62)$$

$$\therefore v_z = 0 \blacksquare \quad (63)$$

## Hagen-Poiseuille Flow in a Circular Pipe

### *i) Navier-Stokes Equation for Incompressible Liquids in Cylindrical Coordinates*

Mapping the cartesian z-component from equation (10) to cylindrical coordinates gives:

$$\rho \left( \frac{\partial v_z}{\partial t} + v_r \frac{\partial v_z}{\partial r} + \left( \frac{v_\theta}{r} \right) \left( \frac{\partial v_z}{\partial \theta} \right) + v_z \frac{\partial v_z}{\partial z} \right) = -\frac{\partial p}{\partial z} + \eta \nabla^2 v_z + \rho g_z \quad (64)$$

Assuming no-slip conditions:

$$\frac{\partial p}{\partial z} = \eta \nabla^2 v_z \quad (65)$$

Expanding the Laplacian:

$$\frac{\partial p}{\partial z} = \eta \left[ \frac{1}{r} \left( \frac{\partial}{\partial r} \right) \left( r \frac{\partial v_z}{\partial r} \right) + \frac{1}{r^2} \left( \frac{\partial^2 v_z}{\partial \theta^2} \right) + \frac{\partial^2 v_z}{\partial z^2} \right] \quad (66)$$

Reducing terms due to no slip conditions and simplifying gives us the Poiseuillian Navier-Stokes equation in cylindrical coordinates:

$$\frac{\partial p}{\partial z} = \frac{\eta}{r} \left[ \left( \frac{\partial}{\partial r} \right) \left( r \frac{\partial v_z}{\partial r} \right) \right] \quad (67)$$

$$\left( \frac{r}{\eta} \right) \left( \frac{\partial p}{\partial z} \right) dr = \partial \left( r \frac{\partial v_z}{\partial r} \right) \quad \square \quad (68)$$

### *ii) Derivation of Velocity*

Equations (47) & (68) are analogous, so the method used to derive equation (53) may be used here as well. As with equation (47) let the boundary conditions be  $r_0 = 0$ ,  $v_{z_0} = 0$ :

$$\int \left( \frac{r}{\eta} \right) \left( \frac{\partial p}{\partial z} \right) dr = \int \partial \left( r \frac{\partial v_z}{\partial r} \right) \quad (69)$$

$$\left( \frac{r^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) = r \left( \frac{\partial v_z}{\partial r} \right) + C_0 \quad (70)$$

$$\therefore C_0 = \left( \frac{r_0^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) - r_0 \left( \frac{\partial v_z}{\partial r_0} \right) = 0 \quad (71)$$

$$\therefore \left( \frac{r^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) = r \left( \frac{\partial v_z}{\partial r} \right) \quad \square \quad (72)$$

Equations (72) & (53) are analogous, so the same method applies:

$$\int \left( \frac{r^2}{2\eta} \right) \left( \frac{\partial p}{\partial z} \right) dr = \int r \left( \frac{\partial v_z}{\partial r} \right) \quad (73)$$

$$v_z = \left( \frac{r^2}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) + C_1 \quad (74)$$

$$C_1 = v_{z_1} - \left( \frac{r_1^2}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) \quad (75)$$

$$C_1 = - \left( \frac{r_1^2}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) \quad (76)$$

$$\therefore v_z(r, \theta) = - \left( \frac{1}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) (r_1^2 - r^2) \quad \blacksquare \quad (77)$$

### iii) Compliance with No-Slip Conditions

By setting the radius ( $r^2$ ) to the boundary, from equation we get (77):

$$v_z(r, \theta) = - \left( \frac{1}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) (r_1^2 - r_1^2) \quad (78)$$

$$v_z(r, \theta) = - \left( \frac{1}{4\eta} \right) \left( \frac{\partial p}{\partial z} \right) (0) \quad (79)$$

$$\therefore v_z(r, \theta) = 0 \quad \blacksquare \quad (80)$$

We can prove no-slip conditions in a circular pipe in cartesian coordinates as well. To convert back we set  $\frac{\partial p}{\partial z} = \frac{\Delta p}{L_0}$ , and  $r^2 = a^2$ . Since  $\mathcal{C}$  is a circle, any point on  $\partial \mathcal{C}$  can be used to derive the radius:  $r = a = \sqrt{x_{boundary}^2 + y_{boundary}^2}$ . If we make these substitutions into equation (77) it is trivial to prove compliance with no-slip boundary conditions:

$$v_z(x, y) = - \left( \frac{\Delta p}{4\eta L_0} \right) \left( a^2 - \left( \sqrt{x_{boundary}^2 + y_{boundary}^2} \right)^2 \right) \quad (81)$$

$$v_z(x, y) = - \left( \frac{\Delta p}{4\eta L_0} \right) (a^2 - a^2) \quad (82)$$

$$\therefore v_z(x, y) = 0 \quad \blacksquare \quad (83)$$

## 4

### Experimental Verification of Hagen-Poiseuille's Law

#### i) Derivation of Hagen-Poiseuille's Law

Flow rate ( $Q$ ) is obtained by integrating the velocity by the area of our cross-section  $\mathcal{C}$ . We must define some terms before performing the integration. First, let us define the bounds of integration on  $\mathcal{C}$ . Given a circular cross-section, the bounds will be from the minimum radius in the center of  $\mathcal{C}$ ,  $r_{min} = 0$ , to the maximum radius on  $\partial \mathcal{C}$ ,  $r_{max} = R$ . Next we will define  $\frac{\partial p}{\partial z}$  as  $\frac{\partial p}{\partial z} = \frac{\Delta p}{L_0}$ . Finally, we must define our area of integration and the Jacobian (scaling factor). The area of integration,  $dA$ , will be  $2\pi$  and the Jacobian for cylindrical coordinates is simply  $J(r, \theta, z) = r$ . Now we are ready to derive  $Q$ :

$$Q = \int_{r_{min}}^{r_{max}} v_z J(r, \theta, z) dA \quad (84)$$

$$= \int_{r=0}^{r=R} -\left(\frac{1}{4\eta}\right) \left(\frac{\Delta p}{L_0}\right) (R^2 - r^2) r 2\pi dr \quad (85)$$

$$= -\left(\frac{\pi}{2\eta}\right) \left(\frac{\Delta p}{L_0}\right) \int_{r=0}^{r=R} (R^2 r - r^3) dr \quad (86)$$

$$= -\left(\frac{\pi}{2\eta}\right) \left(\frac{\Delta p}{L_0}\right) \left(\frac{R^2 r^2}{2} - \frac{r^4}{4}\right) \Big|_{r=0}^{r=R} \quad (87)$$

$$= -\left(\frac{\pi}{2\eta}\right) \left(\frac{\Delta p}{L_0}\right) \left(\frac{R^4}{4}\right) \quad (88)$$

$$= -\left(\frac{R^4 \pi}{8\eta}\right) \left(\frac{\Delta p}{L_0}\right) \quad \square \quad (89)$$