

sr.no.	Positive scenario	negative scenario
1	Verify that the dimensions of the oven are as per the specification provided.	Check oven's condition when it runs for specific hours
2	Verify that the oven's material is optimal for its use as an oven and as per the specification.	Check that disconnecting power while cooking is in progress
3	Verify that the oven heats the food at the desired temperature properly.	check the switch when use microwave oven.
4	Verify that the oven heats food at the desired temperature within a specified time duration.	microwave oven nothing use without electricity.
5	Verify the ovens functioning with the maximum attainable temperature.	Check how the oven acts when the user can open the compartment with a fake key.
6	Verify the ovens functioning with minimum attainable temperature.	Check whether the oven can give an electric shock to the user if touched with bare hands and feet on the floor.
7	Verify that the oven's plate rotation speed is optimal and not too high to spill the food kept over it.	
8	Verify that the oven's door gets closed properly.	
9	Verify that the oven's door opens smoothly.	
10	Verify the battery requirement of the microwave oven and check that it function's smoothly at that power.	
11	Verify that the text written over the oven's body is clearly readable.	
12	Verify that the digital display is clearly visible and functions correctly.	
13	Verify that the temperature regulator is smooth to operate.	
14	Verify that the temperature regulator works correctly.	
15	Check the maximum capacity of the oven and test its functioning with that volume of food.	
16	Check the oven's functionality with different kinds of food – solid, and liquid.	
17	Check the oven's functionality with different food at different temperatures.	
18	Verify the oven's functionality with different kinds of container material.	
19	Verify that the power cord of the oven is long enough.	
20	Verify that the usage instruction or user manuals have clear instructions.	
21	Check that the alarm sound system is properly working or not	
22	Check that glass rotation speed is as expected	
23	Check that the digital displayed screen should be properly visible to users	