

557. A stop valve placed in the service pipe near its connection with the water main is called:

(a) Service cock

(c) Stop cock

(b) Corporation cock

(d) Gate valve



557. A stop valve placed in the service pipe near its connection with the water main is called:

(a) Service cock

(c) Stop cock

(b) Corporation cock

(d) Gate valve

