

580. The hubless is used in lieu of the pipe when caulking and jointing of the pipe is quite difficult. The hubless pipe (cast iron) is easily joined by the use of _____

- | | |
|-----------------------------|--------------------|
| (a) Neoprene rubber sleeves | (c) Oakum |
| (b) Lead | (d) Solvent Cement |



580. The hubless is used in lieu of the pipe when caulking and jointing of the pipe is quite difficult. The hubless pipe (cast iron) is easily joined by the use of _____

- | | |
|-----------------------------|--------------------|
| (a) Neoprene rubber sleeves | (c) Oakum |
| (b) Lead | (d) Solvent Cement |

