

Wemo Robot C axis enable procedure

Wemo Robot C axis enable procedure

Insert Pendrive (With C program loaded)

Select Yes

Select Restore

Select Config

Select No

Select Ok

Select Service

Select Program/Service

PW 159357

Select ESC

Select Save Button

Select Ok