

Assignment 1

Answer 1 :

The Radon transform data is often called a sinogram because the Radon transform of an off-center point source is sinusoidal.

Consequently, we see that the Radon transform of a number of small objects appears graphically as a number of blurred sine waves with different amplitudes and phases.

(this answer is not final. More explanation may have to be added to it)