


Wiring Diagram




NOTE: Above diagram for 20No. PTL With Control System
REQUIRED POWER: Single Phase 230V AC, 50Hz, 2KW with Neutral & Earth for Total 360 PTL

NOTE: All Devices and shield earthing properly	
WIRING DONE BY	
WIRING CHECKED BY	

NOTE: Electrical wiring diagram may be change at the time of final design

DESIGNED BY	VIMAL	PTL CABLE CONNECTION DIAGRAM PTL SYSTEM (Ref-343)	
CHECKED BY			
		FALCON AUTOTECH PVT. LTD. Plot No. 308-309,Eco Tech Ext-1, Greater Noida, UP-201308	DRW.NO
			T-343-E01
			REV NO
			00




NOTE: All Devices and shield earthing properly

WIRING DONE BY	
WIRING CHECKED BY	


NOTE: Electrical wiring diagram may be change at the time of final design

DESIGNED BY	VIMAL	PTL BOX LANE WIRING DIAGRAM PTL SYSTEM (Ref-343)			
CHECKED BY					
		FALCON AUTOTECH PVT. LTD. Plot No. 308-309,Eco Tech Ext-1, Greater Noida, UP-201308		DRW NO.	T-343-E02


PTL BOX PANEL SHEET



PTL BOX FRONT VIEW



PTL BOX RIGHT SIDE VIEW



NOTE: All Devices and shield earthing properly

WIRING DONE BY	
WIRING CHECKED BY	

NOTE: Panel Layout may be change at the time of final design

DESIGNED BY	VIMAL	Panel Layout PTL SYSTEM (Ref-343)		
CHECKED BY				
		FALCON AUTOTECH PVT. LTD. Plot No. 308-309,Eco Tech Ext-1, Greater Noida, UP-201308	DRW.NO	T-343-E03
			REV NO	00