

CHANGE LOG V3e -> V3f

- move switch
- added level converter
- added flags

V3f -> V3g

- added Vdd and 3V3 LED status

V3g -> V3h

- updated LEDVDD to 3.3V
- added test points on SPI

V3h -> V3i

- rollback LEDVDD to 5V
- replaced level-converter to BSS138



