



- trace right of LED20 moved to allow ground pour
- adjusted spacing GPIO0, SDA, SCL
- adjusted VBAT trace going to R1
- adjusted VDD on R7 & C25
- moved battery up by a few mm
- changed the stiffner under the SAO conn



Note:
Flexible PCB 0.2mm FPC
Stiffener 0.8mm FR4